TEKTRONIX®

1478

CALIBRATED
CHROMINANCE
LEVEL CORRECTOR

INSTRUCTION MANUAL

Tektronix, Inc. P.O. Box 500 Beaverton, Oregon 97005

Serial Number



All TEKTRONIX instruments are warranted against defective materials and workmanship for one year. Any questions with respect to the warranty should be taken up with your TEKTRONIX Field Engineer or representative.

All requests for repair and replacement parts should be directed to the TEKTRONIX Field Office or representative in your area. This will assure you the fastest possible service. Please include the instrument Type Number or Part Number and Serial Number with all requests for parts or service.

Specifications and price change privileges reserved.

Copyright © 1973 by Tektronix, Inc., Beaverton, Oregon. Printed in the United States of America. All rights reserved. Contents of this publication may not be reproduced in any form without permission of Tektronix, Inc.

U.S.A. and Foreign TEKTRONIX products covered by U.S. and foreign patents and/or patents pending.

TEKTRONIX is a registered trademark of Tektronix, Inc.

TABLE OF CONTENTS

ELECTRICAL CHARACTERISTICS	Pag
Input to Output Chrominance to Luminance Waveform Distortion Bypass Relay and Power	1 2 2 2
ENVIRONMENTAL CONSIDERATIONS	2
1478 INSTALLATION	3
CONNECTORS AND CONTROLS	5
PHYSICAL SIZE	5
OPERATING INSTRUCTIONS	5
Placing The 1478 in The Program Line Correcting Chrominance Level Measuring Chroma Delay Applying Chrominance Correction The Monitor Channel Bypassing The 1478 Increased Correction Range	5 6 6 6 6 7
SERVICING	7
Cleaning Visual Inspection Lubrication Replacement Parts PROCEDURE FOR RECALIBRATION Test Equipment Required Adjustment Procedure Calibration Checks	7 7 7 7 8 8 8 8
CIRCUIT DESCRIPTION	15
Block Diagram Interface Input Amplifier Aperture Correction Output Amplifiers Power Supply	15 15 15 15 16 16
ELECTRICAL PARTS LIST	17
DIAGRAMS, CIRCUIT BOARD ILLUSTRATIONS, MECHANICAL PARTS LIST AND PACKAGING	
CHARLOE INTEGRALATION	




Fig. 1. The 1478 Calibrated Chrominance Level Corrector.

CALIBRATED CHROMINANCE LEVEL CORRECTOR

The 1478 CALIBRATED CHROMINANCE LEVEL CORRECTOR is for use with NTSC, PAL and PAL M color video signals. Using the modulated sine-squared pulse technique, relative chrominance to luminance gain errors can be manually corrected and the chrominance to luminance delay measured.

In addition to the in-line PROGRAM CHANNEL, the 1478 has a MONITOR CHANNEL, allowing the chrominance to luminance gain correction to be previewed prior to program line application. A waveform monitor, used in the MONITOR CHANNEL, allows direct measurement of the chrominance to luminance delay. The delay may also be plotted on nomograph. The waveform monitor used in the MONITOR CHANNEL can also be used for measuring other signal distortions.

Both the PROGRAM CHANNEL and the MONITOR CHANNEL are controlled by their own CORRECTED and UNCORRECTED pushbutton switches, allowing the chrominance gain correction to be applied to either or both channels. The CHROMA GAIN dial, used for the chrominance to luminance gain correction, is variable from 0.60 to 1.59 in .01 steps.

The continuity of the program line is protected by a bypass relay. The relay automatically bypasses the program line, through a delay line, in the event of a power failure. The 1478 may be removed from the equipment rack with minimum disruption of the program line; no time difference between the corrected or bypassed signal will be observed.

ELECTRICAL CHARACTERISTICS

The electrical performance requirements for this instrument are valid over the environmental limits at the end of this characteristics section. Calibration within an ambient temperature range of $+20^{\circ}\text{C}$ to $+30^{\circ}\text{C}$ and a warm-up period of 10 minutes are required prior to achieving stated accuracies.

TABLE 1
INPUT TO OUTPUT

Characteristic	Performance Requirement
Input Impedance	75 Ω
(AC coupled)	,
Land Circuit Land	Composite Video 1.0 V ±0.2 V
Input Signal Level	Video Signal Only 0.7 V ±0.14 V
Through Gain	1 ±0.5%
Multi Burst Flatness	1% to 5 MHz
Chrominance Gain	3.58 & 4.43 MHz
	0.60 to 1.59 (in .01 ±1% steps)
Phase Delay at 3.58 MHz	≅215° (matched ±3°)
Operating and Bypassed	4 ,
Time Delay	≅145 ns
Operating or Bypass	,
Output DC Level	0 V ±20 mV
(No Input Signal; input AC coupled)	2
Output Impedance	75 Ω
Return Loss	a s
Input	46 dB to 5 MHz
Output	34 dB to 5 MHz
Bypass	40 dB to 5 MHz

TABLE 2
CHROMINANCE TO LUMINANCE

Characteristic	Performance Requirement			
Relative Delay	5 ns or less			
3.58 & 4.43 MHz				
Ø Shift With Chroma Gain Change		±1°		
2T Pulse: Bar Ratio	<u>.70</u>	1.0	1.41	
21 Fulse. Bai Matio	≅.92	.99-1.09	≅1.10	
2T Pulse Overshoot and Preshoot		1%	≅5%	
T Pulse: Bar Ratio				
100 ns HAD	≅.85	.98-1.02	≅ 1.20	
125 ns HAD	≅.85	.98-1.02	≅1.20	
T Step Overshoot				
100 ns HAD		3%	≅7%	
125 ns HAD	v	3%	≅5%	
T Step Preshoot				
100 ns HAD	N	3%	≅7 %	
125 ns HAD		3%	≅6%	
T Step Risetime				
100 ns HAD	≅140 ns		≅80 ns	
125 ns HAD	≅155 ns		≅95 ns	

TABLE 3
WAVEFORM DISTORTION

	Characteristic	Performance	Requirement	
Linear Distortions				
	Field Time Tilt	0.5%		
	Line Time Tilt	0.5%		
	Short Time Dis-	T Pulse	2T Pulse	
	tortion (ringing)	3%	1%	

Continuous Ran- dom Noise (un- weighted)	−66 dB to 5 MHz
Non-Linear Dis- tortions	
Line Time Non-Linearity	0.5%
Differential Gain	0.5%
Differential Phase	0.5°
Chrominance to Luminance Inter- modulation	0.5%
Dynamic Picture Gain	0.5%
Dynamic Sync Gain	0.5%

TABLE 4
BYPASS RELAY AND POWER

Characteristic	Performance Requirement		
Relay Delay	17		
On	0.25 second or more		
Off	One-fourth field or less		
Line Voltage	115 or 230 VAC ±10%		
Maximum Power Consumption	≅20 Watts		

ENVIRONMENTAL CONSIDERATIONS

The 1478 requires calibration at ± 20 to $\pm 30^{\circ}$ C and a warm-up of 10 minutes, at temperature, to operate within the stated performance requirements. The performance requirements for this instrument are valid over an operating temperature range of 0 to $\pm 50^{\circ}$ C, at altitudes up to 15,000 feet. Additionally, storage (non-operating) at temperatures of ± 40 to $\pm 65^{\circ}$ C and altitude variations up to $\pm 50,000$ feet will not endanger performance.




Fig. 2. 1478 Installation.




Fig. 3.

CONNECTORS AND CONTROLS

Interface Connectors

1 Program In

75 Ω program signal line input.

(2) Program Out

Program signal output after signal processing in 1478, or bypassed through a delay line from Program In.

(3) Monitor Out

Provides a choice of previewing and monitoring the correction being applied to the program line, or monitoring the incoming uncorrected signal.

4 Remote

Provides for remote control of bypass relay.

(5)

Interface to 1478 plug and jack assemblies provide the signal access to and from the 1478.

1478 Rear Panel

6 Power Plug

7 Fuse Holder

1478 Front Panel Connectors and Controls

8 Input

High-impedance signal input test jack.

9 Output

High-impedance signal output test jack.

Program
Channel Corrected/Uncorrected

Self-canceling pushbutton switch that applies the chroma gain correction to the program channel output amplifier.

Monitor
Channel Corrected/Uncorrected

Self-canceling pushbutton switch that applies the chroma gain correction to the monitor channel output amplifier.

12 Chroma Gain

A dual switch assembly, with direct reading knobs, that controls the gain of the chroma correction.

13) Fuse Open

Neon lamp lights if fuse is blown.

(14) Power

Toggle switch with green indicator lamp to indicate when power is present in the instrument. 1478 automatically returns to bypass when power switch is turned off.

15 Remote Bypass

Light that indicates remote switching to the bypass mode. Controlled through the Remote connector on the interface.

TABLE 5
PHYSICAL SIZE

Characteristic	Performance Requirement	
Dimensions		
Height	1.75 inches	
Width	19.00 inches	
Depth	16.89 inches (including interface)	
Weight		
Net	≅10 lbs or 4,5 kg	
Shipping	≅17 lbs or 7.7 kg	

OPERATING INSTRUCTIONS

Placing The 1478 In The Program Line

Route the program line through the 1478 Interface PROGRAM IN and PROGRAM OUTPUT. Connect a waveform monitor to the MONITOR OUTPUT. Push both UNCORRECTED pushbuttons, set the CHROMA GAIN dial to 1.00, and apply power.

Correcting Chrominance Level

Display the Vertical Interval Test Signal on the waveform monitor. Use the Sin² Modulated Pulse, 10T, 12.5T or 20T, as the test signal.

Push the MONITOR CHANNEL CORRECTED pushbutton and adjust the CHROMA GAIN dial until the bottom of the modulation envelope crosses the baseline at the center of the pulse. This is a chrominance to luminance ratio of 1:1.




Fig. 4. Chroma Gain.

The CHROMA GAIN dial indicates the amount of correction required to restore a chrominance to luminance ratio of 1:1. If for example, the dial reads 1.41, a 41% (3 dB) boost in chrominance returns the ratio to 1:1. Conversely, if the dial reading is 0.70, a 30% (-3 dB) attenuation of the chrominance is required to restore the 1:1 chrominance to luminance ratio.

Input relative chrominance level is the reciprocal of the CHROMA GAIN dial indication

$$\left(RCL^{in} = \frac{1}{chroma gain} \right)$$
. See Table 6.

Measuring Chroma Delay

After the chrominance level is corrected, the chroma delay can be measured. Chroma delay is determined by the envelope variation from the baseline. Chroma delay is 10 ns per IRE unit of baseline offset (peak to peak).




Fig. 5. Measuring Chroma Delay.

Applying Chrominance Correction

The chrominance level correction is applied to the program line by depressing the PROGRAM CHANNEL CORRECTION pushbutton. The program line correction can be continuously monitored by keeping the correction applied to the MONITOR CHANNEL.

The Monitor Channel

The monitor and program channel amplifiers operate independently, making it possible to continue to monitor the chroma corrected output or the uncorrected input signal. Additionally, if desired, the waveform monitor may be used for other measurements within its capability.

Bypassing The 1478

If the 1478 line voltage source is interrupted or the POWER switch is turned off, the program line switches to bypass. The program line is bypassed through a passive

TABLE 6

Determing Measured Value of Relative Chroma Level from Chroma Gain.

Dial Reading	.00	.01	.02	.03	.04	.05	.06	.07	.08	.09
			,	0		2				
.6	1.67	1.64	1.61	1.59	1.56	1.54	1.52	1.49	1.47	1.45
.7	1.43	1.41	1.39	1.37	1.35	1.33	1.32	1.30	1.28	1.27
.8	1.25	1.23	1.22	1.20	1.19	1.18	1.16	1.15	1.14	1.12
.9	1.11	1.10	1.09	1.08	1.06	1.05	1.04	1.03	1.02	1.01
1.0	1.00	.99	.98	.97	.96	.95	.94	.93	.93	.92
1.1	.91	.90	.89	.88	.88	.87	.86	.85	.85	.84
1.2	.83	.83	.82	.81	.81	.80	.79	.79	.78	.78
1.3	.77	.76	.76	.75	.75	.74	.74	.73	.72	.72
1.4	.71	.71	.70	.70	.69	.69	.68	.68	.68	.67
1.5	.67	.66	.66	.65	.65	.65	.64	.64	.63	.63

If the dial reading, for example, is 1.41 (1.4 +.01) the relative chroma level is .71.

delay line equal to the 1478 operating delay. Thus, there is no change in signal delay between the through and bypassed conditions.

Remote bypass is available through the REMOTE connector, located on the interface. A front panel REMOTE BYPASS indicator is provided to indicate when the 1478 has been bypassed from a remote source.

Increased Correction Range

If the 0.60 to 1.59 chroma gain correction range is insufficient, it is possible to modify the 1478 for a range of approximately 0 to 2.




Fig. 6. Increasing Correction Range.

To change the gain range, remove P741 and install a 10 k variable resistor. When this resistor is set to the \pm 15 volt end, the relative chroma level is 2; at the \pm 15 volt end, all chroma is canceled. Adjustment of R567 may be necessary to null chroma to 0 (refer to adjustment procedure step 12 to readjust chroma gain).

SERVICING

A routine servicing program can forestall or avert many failures. The severity of the operating environment sets the frequency of routine servicing, however, we recommend a calibration check after 1000 hours or six months of operation. Recalibration should always be preceded by a thorough cleaning and visual inspection.

Cleaning

The accumulation of dust within the 1478 can cause damage as well as mar the appearance of the instrument. The best method of removing loose dust is with low velocity air. Then, use a soft cloth dampened with a solution of mild detergent and water, plus cotton swabs and a paint brush to remove any remaining dirt.

Do not use harsh detergents, solvents that dissolve plastics, or large amounts of water to clean this instrument.

Visual Inspection

A superfical inspection of the 1478 should be all that is necessary, unless some unusual operation has been observed. Look for heat damage, loose connections or plugs, improperly seated ICs or transistors, damaged switches, or other obvious damage.

Lubrication

The CHROMA GAIN switch should be lubricated occasionally. The detents should be lubricated with a non-conductive lubricant, formulated for this purpose. Use a contact cleaning form of lubricant on the rotors and contacts. Do not over-lubricate.

Transistor and Integrated Circuit Testing

We discourage removing transistors and integrated circuits from their sockets for routine testing.

Replacement Parts

All replacement parts for Tektronix instruments are available from Tektronix, Inc. Our nearest Field Office or representative will be glad to assist you in their procurement. Many of the components used in this instrument are

available from local parts distributors. Local purchase of common parts will reduce the time required for repairs. Be sure to check the parts list for a complete description before ordering or replacing any part.

Some components used in Tektronix instruments are designated as special parts. They are selected or manufactured by Tektronix, Inc., to meet specific performance requirements. Special parts are always identified in the parts list column headed Description.

When ordering replacement parts from Tektronix, Inc., please include the following information:

- 1. Instrument type.
- 2. Instrument serial number.
- 3. Circuit number and description from the parts list.
- 4. The Tektronix part number of the component.

PROCEDURE FOR RECALIBRATION

The following readjustment procedure may also be used as a checkout. If any adjustments are made, complete readjustment and checkout should be performed to remove all interaction.

When the procedure calls for a specific signal, refer to that signal generator instruction manual for its operating instructions.

Test Equipment Required

The following instruments and accessories are required for recalibration. The Tektronix instrument types that are used for factory calibration appear in parentheses. Other equipment with equal or superior specifications will also suffice.

- 1. NTSC Test Signal Generator (149A) or (148) Insertion Test Signal Generator for PAL signals
- Vectorscope NTSC (520A), PAL (521A) or PAL M (522A)
- 3. Waveform Monitor NTSC (529) or PAL & PAL M (529-188D)

- 4. Test Oscilloscope with Differential Comparator Amplifier plug-in (547 with 1A5)
 - 5. Return Loss Bridge (Tektronix 015-0149-00)
 - 6. Constant-Amplitude Signal Generator (191)
- 7. 50 Ω to 75 Ω minimum loss attenuator (Tektronix 011-0057-00)
 - 8. Chopped Voltage Reference (Tektronix 067-0596-00)
- 9. 75 Ω Voltage Step-up Termination (Tektronix 011-0100-01) NTSC; (Tektronix 011-0109-00) PAL
 - 10. DC voltmeter
 - 11. Variable autotransformer

Adjustment Procedure

1. Adjust Interface Return Loss

- a. Disconnect the 1478 from the Interface. Use the Return Loss Bridge, driven with a 250 mV constant amplitude signal, to check return loss at both PROGRAM IN and OUT. Consult the Return Loss Bridge instruction manual for operating instructions. Check return loss at a number of frequencies up to 5 MHz.
- b. If return loss is $-40\,\mathrm{dB}$ or more, disregard the remainder of this step.
- c. Drive the Input of the Return Loss Bridge with the Sin² Modulated Pulse and Bar signal from the Test Signal Generator. Use test oscilloscope delaying sweep to place only the T pulse on the test oscilloscope graticule. Adjust the bypass delay line variable capacitors for minimum amplitude and ringing.
- d. Recheck return loss with the constant amplitude signal.

2. Check Power Supply Regulation

Install the 1478 into the Interface and plug the line cord into the variable autotransformer. Turn the 1478 POWER ON. Use the DC voltmeter to check for approximately -15 volts and +15 volts. Vary the autotransformer and check for constant power supply voltages 10% above and below the rated line voltage (115 VAC $\pm 10\%$).




Fig. 7. Adjustment Locations.

3. Adjust 1478 Return Loss

- a. Connect the unknown arm of the Return Loss Bridge to the 1478 PROGRAM IN. Drive the bridge with 250 mV of 50 kHz constant amplitude signal and adjust R968 for minimum display amplitude.
- b. Change the driving signal to 5 MHz and adjust C968 for minimum display amplitude.
- c. Check PROGRAM IN return loss, -46 dB or more; PROGRAM OUT return loss, -34 dB or more. It may be necessary to change the setting of R864, when checking PROGRAM OUT return loss, to bring the display on the screen.

4. Set Luminance Gains

- a. Use the test oscilloscope in the differential mode to match the output of the Chopped Voltage Reference to a 50 IRE Full Field signal from the Test Signal Generator.
- b. Apply the 50 IRE signal to the 1478 PROGRAM IN. Connect the 1478 PROGRAM OUT, along with the Chopped Voltage Reference, to the test oscilloscope vertical differential amplifier. Adjust the program amplifier Luminance Gain, R210, to match the Chopped Voltage Reference.
- c. Connect the MONITOR OUT to the test oscilloscope vertical differential amplifier and adjust the monitor amplifier Luminance Gain, R280, to match the Chopped Voltage Reference.

5. Set The Output DC Level

- a. Disconnect the 1478 PROGRAM IN signal and connect the PROGRAM OUT to the Waveform Monitor.
- b. Turn off the 1478 and set the Waveform Monitor trace to the 0 IRE reference. Turn the 1478 POWER ON and adjust the Output DC Level, R864, to return the trace to the 0 IRE reference.

NOTE

The following six steps require signals from the Test Signal Generator and use the same monitors. In addition, these steps interact, so repeat them until there is no further need for adjustment.

Connections

Loop-thru connect the Vectorscope to the Waveform Monitor and the 1478 PROGRAM OUT. Terminate in 75 Ω . Connect the Modulated Sin² Pulse and Bar signal from the Test Signal Generator to the 1478 PROGRAM IN.

6. Adjust T Pulse Response

Observe the Waveform Monitor and adjust R782 and C882 for the least ringing following the T pulse.

7. Adjust Multiburst Flatness

Change the input signal to Multiburst and connect the test oscilloscope probe to the junction of R720 and R745. Adjust C761 for optimum flat top and bottom to the multiburst packets. Remove the test oscilloscope probe.

8. Adjust Program Channel Operating Delay

- a. Change the input signal to Sin² Modulated Pulse and Bar and observe the Vectorscope. Turn off the 1478 POWER and position the vector to the horizontal graticule axis. Turn the 1478 POWER ON.
- b. Adjust the program channel Operating Delay, C216, to return the vector to the horizontal axis.

9. Adjust Program Channel Chroma Gain

Observe the Waveform Monitor display and adjust the program channel Chroma Gain, R503, for a flat baseline under the modulated pulse and equal T pulse and bar amplitudes.

10. Adjust Chroma Phase

- a. Observe the Vectorscope display. Remove P741 and connect a 10 $k\Omega$ variable resistor so that the voltage at R665 can swing between +15 V and -15 V (see Fig. 6, in the operating instructions). Depress PROGRAM CHANNEL CORRECTED.
- b. Rotate the 10 $k\Omega$ variable resistor back and forth and adjust C458 and R657 to pass the vector tip through 0 on the horizontal axis. Adjustment of R567 may be necessary to pass the vector tip through zero.

11. Adjust T Pulse Tracking

a. Depress the PROGRAM CHANNEL UNCOR-RECTED and observe the Waveform Monitor. Set the variable resistor for 5 to 10 IRE units of T pulse negative preshoot and baseline overshoot. b. Adjust T Pulse Tracking, C787, for equal amounts of preshoot and baseline overshoot.

NOTE

The preceding six steps interact; repeat them until no further adjustment is necessary. Remove the variable resistor and replace P741 before proceeding.

12. Adjust Chroma Gain Correction

- a. Apply the Modulated Linearity signal from the Test Signal Generator to the 1478 PROGRAM INPUT. Connect the PROGRAM OUT through a 75 Ω Voltage Step-up Termination to one input of the test oscilloscope differential plug-in. Connect the output of the Chopped Voltage Reference to the other differential input.
- b. Depress the PROGRAM CHANNEL UNCOR-RECTED and bring the chroma packets together, but not overlapped, with the Chopped Voltage Reference. This is an uncorrected gain of one.
- c. Depress the PROGRAM CHANNEL CORRECTED and set the CHROMA GAIN dial to 1.00. Adjust the Chroma Correction Gain, R567, until the chroma packets again meet. This is the corrected chroma gain of one.

13. Adjust Chroma Gain Tracking

- a. Read the Chopped Voltage Reference dial. The dial reading is for a gain of one. Multiply this reading by 1.5 and 0.6 to determine the Chopped Voltage Reference settings used for adjusting the CHROMA GAIN dial tracking.
- b. Set the Chopped Voltage Reference to the calculated 1.5 setting and set the CHROMA GAIN dial to 1.50.

- c. Adjust the X1.5 Gain, R756, until the chroma packets meet.
- d. Set the Chopped Voltage Reference to the calculated 0.6 setting and set the CHROMA GAIN dial to .60.
- e. Adjust the X0.6 Gain, R856, until the chroma packets meet.

14. Adjust Monitor Channel Operating Delay


- a. Connect the Vectorscope to the 1478 PROGRAM OUT. Connect the Modulated Sin² Pulse and Bar signal from the Test Signal Generator to the 1478 PROGRAM IN.
- b. Turn the 1478 POWER off (placing the 1478 in the bypassed mode) and set the vector on the horizontal graticule axis. Move the output cable to the MONITOR OUT and turn the 1478 POWER ON.
- c. Adjust the monitor channel Operating Delay, C276, to return the vector to the horizontal graticule axis.

15. Adjust Monitor Channel Chroma Gain


- a. Connect the Waveform Monitor to the MONITOR OUT. Check to see that the Modulated Sin² Pulse and Bar signal is displayed.
- b. Adjust the monitor channel Chroma Gain, R371, for a flat base line under the modulated pulse and equal T pulse and bar amplitudes.

16. Calibration Checks


The following checks should be made; however, some or all can be deleted if the parameters involved are not critical. The table is arranged by the signal monitors required.




Staircase Waveform




Modulated Staircase Waveform (Variable APL)



Modulated Pedestal waveform



Modulated Sin² Pulse & Bar Waveform



Field Rate Squarewave

Fig. 8. Signals Required For Calibration Checks.

TABLE 7
CALIBRATION CHECKS

Test	Signal Required	Tolerance	
	Vectorscope		
Differential Gain	Staircase	0.5%	
Differential Phase	Staircase	0.5°	
Line Time Non-Linearity (use luminance mode)	Staircase	0.5%	Luu
	Waveform Monitor		»
Dynamic Picture Gain	Variable APL (10–90)	0.5%	
Dynamic Sync Gain	Variable APL (10–90)	0.5%	
Chrominance: Luminance Intermodulation (low pass)	Modulated Pedestal (Variable APL 40–70)	0.5%	
Chrominance: Luminance Relative Delay	Modulated Sin ² Pulse and Bar	≤5 ns	

TABLE 7 (cont)

	Test Oscilloscope		
2T Pulse: Bar Ratio	Modulated Sin ² Pulse and Bar	.99-1.01:1	\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \
2T Pulse Preshoot & Baseline Overshoot	Modulated Sin ² Pulse and Bar	1%	
T Pulse: Bar Ratio	Modulated Sin ² Pulse and Bar	.98-1.02:1	
T Step Preshoot & Overshoot	Modulated Sin ² Pulse and Bar	3%	/\
T Step Risetime	Modulated Sin ² Pulse and Bar	125 ns (NTSC) 100 ns (PAL)	
Line Time Tilt	Modulated Sin ² Pulse and Bar	0.5%	
Field Time Tilt	Field Rate Square Wave	0.5%	




Fig. 9. Block Diagram.

CIRCUIT DESCRIPTION

Interface

The Interface provides a constant program line, either through or around the 1478, and signal access to and from the 1478.

The program line is controlled by K475, which operates as a normally-open quick-release circuit, allowing rapid switching to bypass when power is lost. The relay is delayed at turn-on to allow the 1478 to stabilize prior to applying the program line.

The relay is controlled by turning Q642 on and off. Q742 turns on Q642 after a period determined by the time constant of R775 and C875 (≅.5 second). Conversely, Q642 turns off instantly when power loss occurs. The charge on C570 is coupled through CR675 to the base of Q642, holding it up, while the emitter starts down, causing the relay to switch to bypass in less than one-fourth field.

Remote bypass is available through the REMOTE plug located on the Interface rear panel. Whenever the ground path through the REMOTE plug is opened, K475 opens and Q340 is turned on. When Q340 is on, the front panel REMOTE BYPASS indicator is lit.

Input Amplifier

The input amplifier is an inverting operational amplifier, consisting of Q864, Q663 and Q661. The amplifier gain is about 1.3. Input signal termination is C968 and R968, C761 sets flatness, and R864 is the output DC level adjust.

A front panel pin jack test point, allows access to the input signal. The jack is isolated from the input program line by R960.

Aperture Corrector

The signal from the input amplifier drives the 75 Ω aperture corrector delay line. The output end of the delay line drives the base of Q576, a relatively high impedance. The delay line output is unterminated and any reflections are absorbed by the source termination, R782, R795 and C882. The total delay is approximately 125 ns.

Differential inputs to the gain cell, U659 are taken from opposite ends of the delay line. At approximately 4 MHz, the maximum phase difference (180°) occurs across the delay line. This is also the point of maximum possible gain change. C787 adjusts delay for equal gain at 3.58 and 4.43 MHz. The gain output of U659 is a function of current into pin 12.

The current at pin 12 is proportional to the output voltage of U851, which is a direct function of the CHROMA GAIN switch. A positive voltage at the output of U851 causes an in phase, or additive, chroma correction at the emitter of Q508. A negative voltage out of U851 causes an out of phase, or subtractive, chroma correction.

C458 and R657 match the delay of the through signal at Q581 and the correction signal at Q508, to eliminate phase shift when the chroma level is changed.

Output Amplifiers

The through and correction signals are summed at the input of the output amplifiers. The correction signal can be applied to either or both of the identical operational amplifiers. Amplifier gain is about 1.5 and set by R210 and R280. C216 and C276, along with R503 and R371, set the flatness and match the through delay to the bypass delay.

A front panel pin jack test point, allows access to the output signal. The jack is isolated from the output program line by R150.

Power Supply

The power supply for the 1478 provides + and -15 volts. These supplies are not adjustable, their voltage is fixed by the integrated circuit voltage regulators. Full wave bridge rectification is employed in conjunction with the integrated circuit voltage regulators. The regulator circuits are identical, except that the -15 volt regulator has the output and common leads reversed to provide minus output voltage.

The power transformer has a split primary winding allowing rapid conversion for 234 VAC line source. A FUSE OPEN indicator along with a POWER ON light are provided on the front panel.

ELECTRICAL REPLACEABLE PARTS LIST

PARTS ORDERING INFORMATION

Replacement parts are available from or through your local Tektronix, Inc. Field Office or representative.

Changes to Tektronix instruments are sometimes made to accommodate improved components as they become available, and to give you the benefit of the latest circuit improvements developed in our engineering department. It is therefore important, when ordering parts, to include the following information in your order: Part number, instrument type or number, serial number, and modification number if applicable.

If a part you have ordered has been replaced with a new or improved part, your local Tektronix, Inc. Field Office or representative will contact you concerning any change in part number.

Change information, if any, is located at the rear of this manual.

SPECIAL NOTES AND SYMBOLS

X000 Part first added at this serial number

00X Part removed after this serial number

ITEM NAME

In the Parts List, an Item Name is separated from the description by a colon (:). Because of space limitations, an Item Name may sometimes appear as incomplete. For further Item Name identification, the U.S. Federal Cataloging Handbook H6-1 can be utilized where possible.

ABBREVIATIONS

ACTR ASSY CAP CER CKT COMP CONN ELCTLT ELEC FXD	ACTUATOR ASSEMBLY CAPACITOR CERAMIC CIRCUIT COMPOSITION CONNECTOR ELECTROLYTIC ELECTRICAL FIXED	PLSTC QTZ RECP RES RF SEL SEMICOND SENS SEP VAR	PLASTIC QUARTZ RECEPTACLE RESISTOR RADIO FREQUENCY SELECTED SEMICONDUCTOR SENSITIVE SEPARATELY VARIABLE WIREWOUND
		VAR	VARIABLE
INCAND LED NONWIR	INCANDESCENT LIGHT EMITTING DIODE NON WIREWOUND	WW XFMR XTAL	TRANSFORMER CRYSTAL
TACTALL T T/	HOH WILLIAMSOND		

CROSS INDEX MFR. CODE NUMBER TO MANUFACTURER

MFR.C	CODE MANUFACTURER	ADDRESS	CITY,STATE,ZIP
00853	Sangamo Electric Co., S. Carolina Div.	P. O. Box 128	Pickens, SC 29671
01121	Allen-Bradley Co.	1201 2nd St.	Milwaukee, WI 53212
02660	Bunker-Ramo Corp., The, Amphenol	0003 - 05.1	
04713	Connector Div.	2801 S. 25th Ave.	Broadview, IL 60153
04/13	Motorola, Inc., Semiconductor	5005 B W B 11 B1	-1
07263	Products Div.	5005 E. McDowell Rd.	Phoenix, AZ 85008
0/263	Fairchild Semiconductor, A Div. of	464	
07910	Fairchild Camera and Instrument Corp.	464 Ellis St.	Mountain View, CA 94040
08806	Teledyne Semiconductor	12515 Chadron Ave.	Hawthorne, CA 90250
00000	General Electric Co., Miniature Lamp Dept.	V. 1. DV	01 1 1 00 44110
09353	C and K Components, Inc.	Nela PK.	Cleveland, OH 44112
12040		103 Morse Street	Watertown, MA 02172
24931	National Semiconductor Corp.	Commerce Drive	Danbury, CT 06810
56289	Specialty Connector Co., Inc.	3560 Madison Ave.	Indianapolis, IN 46227
63743	Sprague Electric Co.		North Adams, MA 01247
	Ward, Leonard, Electric Co.	31 South St.	Mount Vernon, NY 10550
71400	Bussman Mfg., Division of McGraw		
71744	Edison Co.	2536 W. University St.	St. Louis, MO 63107
	Chicago Miniature Lamp Works	4433 Ravenswood Ave.	Chicago, IL 60640
71785	TRW Electronic Components, Cinch Div.	1501 Morse Ave.	Elk Grove Village, IL 60007
72136	Electro Motive Mfg. Co., Inc., The	South Park and John Streets	Willimantic, CT 06226
72982	Erie Technological Products, Inc.	644 W. 12th St.	Erie, PA 16512
73138	Beckman Instruments, Inc., Helipot Div.	2500 Harbor Blvd.	Fullerton, CA 92634
75042	TRW Electronic Components, IRC		
80009	Philadelphia Div.	401 N. Broad St.	Philadelphia, PA 19108
	Tektronix, Inc.	P. O. Box 500	Beaverton, OR 97005
80294	Bourns, Inc.	1200 Columbia Av.e	Riverside, CA 92507
80740	Beckman Instruments, Inc.	2500 Harbor Blvd.	Fullerton, CA 92634
81483	International Rectifier Corp.	9220 Sunset Blvd.	Los Angeles, CA 90069
82389	Switchcraft, Inc.	5555 N. Elston Ave.	Chicago, IL 60630
90201	Mallory Capacitor Co.	3029 E. Washington St.	Indianapolis, IN 46206
91637	Dale Electronics, Inc.	P. O. Box 609	Columbus, NB 68601
98291	Sealectro Corp.	225 Hoyt	Mamroneck, NY 10544

! / /	$\hat{}$					
п	Ckt No.	Tektronix Part No.	Serial/Model No. Eff Dscont	Name & Description	Mfr Code	Mfr Part Number
11	Al A2	670-2956-00 670-3070-00		CKT BOARD ASSY:APERTURE CORRECTOR CKT BOARD ASSY:RELAY/DELAY	80009 80009	670-2956-00 670-3070-00
П	C105 C170 C185	283-0111-00 283-0111-00 283-0111-00		CAP.,FXD,CER DI:0.1UF,20%,50V CAP.,FXD,CER DI:0.1UF,20%,50V CAP.,FXD,CER DI:0.1UF,20%,50V	72982 72982 72982	8131-050651104M 8131-050651104M 8131-050651104M
-	C216 C225	281-0091-00 283-0111-00		CAP., VAR, CER DI:2-8PF CAP., FXD, CER DI:0.1UF, 20%, 50V	72982 72982	538-011-A2-8 8131-050651104M
П	C235 C245 C255 C270 C276	290-0527-00 290-0527-00 283-0111-00 283-0111-00 281-0091-00		CAP.,FXD,ELEC:15UF,20%,20V CAP.,FXD,ELEC:15UF,20%,20V CAP.,FXD,CER DI:0.1UF,20%,50V CAP.,FXD,CER DI:0.1UF,20%,50V CAP.,VAR,CER DI:2-8PF	90201 90201 72982 72982 72982	TDC156M020FL TDC156M020FL 8131-050651104M 8131-050651104M
П	C342	281-0092-00		CAP., VAR, CER DI:9-35PF	72982	538-011-A2-8 538-011D9-35
П	C344 C346 C348 C365	281-0092-00 283-0601-00 283-0669-00 283-0636-00		CAP.,VAR,CER DI:9-35PF CAP.,FXD,MICA D:22PF,10%,300V CAP.,FXD,MICA D:360PF,1%,500V CAP.,FXD,MICA D:36PF,+/-0.5PF,100V	72982 00853 72136 00853	538-011D9-35 D15-3C220K0 DM15F361F0500 D15-1E360D0
П	C375 C442 C444 C446 C448	283-0639-00 281-0092-00 281-0092-00 283-0601-00 283-0669-00		CAP.,FXD,MICA D:56PF,1%,100V CAP.,VAR,CER DI:9-35PF CAP.,VAR,CER DI:9-35PF CAP.,FXD,MICA D:22PF,10%,300V CAP.,FXD,MICA D:360PF,1%,500V	00853 72982 72982 00853 72136	D15-1E560F0 538-011D9-35 538-011D9-35 D15-3C220K0 DM15F361F0500
Π	C458 C480 C505 C515 C542	281-0091-00 283-0111-00 283-0639-00 283-0111-00 281-0092-00		CAP., VAR, CER DI:2-8PF CAP., FXD, CER DI:0.luf, 20%, 50V CAP., FXD, MICA D:56PF, 1%, 100V CAP., FXD, CER DI:0.luf, 20%, 50V CAP., VAR, CER DI:9-35PF	72982 72982 00853 72982 72982	538-011-A2-8 8131-050651104M D15-1E560F0 8131-050651104M 538-011D9-35
Π	C544 C546 C548 C570 C600	281-0092-00 283-0601-00 283-0669-00 290-0527-00 290-0527-00		CAP., VAR, CER DI:9-35PF CAP., FXD, MICA D:22PF, 10%, 300V CAP., FXD, MICA D:360PF, 1%, 500V CAP., FXD, ELEC:15UF, 20%, 20V CAP., FXD, ELEC:15UF, 20%, 20V	72982 00853 72136 90201 90201	538-011D9-35 D15-3C220K0 DM15F361F0500 TDC156M020FL TDC156M020FL
Π	C610 C642 C644 C645 C646	283-0003-00 281-0092-00 281-0092-00 283-0111-00 283-0637-00		CAP.,FXD,CER DI:0.01UF,+80-20%,150V CAP.,VAR,CER DI:9-35PF CAP.,VAR,CER DI:9-35PF CAP.,FXD,CER DI:0.1UF,20%,50V CAP.,FXD,MICA D:20PF,+/-0.5PF,100V	56289 72982 72982 72982 00853	20C205A1 538-011D9-35 538-011D9-35 8131-050651104M D15-1E200D0
	C648 C650 C665 C685 C715	283-0680-00 290-0527-00 283-0111-00 283-0111-00 283-0000-00		CAP.,FXD,MICA D:330PF,1%,500V CAP.,FXD,ELEC:15UF,20%,20V CAP.,FXD,CER DI:0.1UF,20%,50V CAP.,FXD,CER DI:0.1UF,20%,50V CAP.,FXD,CER DI:0.001UF,+100-0%,500V	72136 90201 72982 72982 56289	DM15E331F05 TDC156M020FL 8131-050651104M 8131-050651104M 40C626
Π	C742 C744 C746 C748 C761	281-0092-00 281-0092-00 283-0637-00 283-0680-00 281-0091-00		CAP., VAR, CER DI:9-35PF CAP., VAR, CER DI:9-35PF CAP., FXD, MICA D:20PF, +/-0.5PF, 100V CAP., FXD, MICA D:330PF, 1%, 500V CAP., VAR, CER DI:2-8PF	72982 72982 00853 72136 72982	538-011D9-35 538-011D9-35 D15-1E200D0 DM15E331F05 538-011-A2-8
Π	C787 C794 C800 C806 C812	281-0092-00 283-0639-00 283-0603-00 283-0603-00 283-0603-00		CAP., VAR, CER DI:9-35PF CAP., FXD, MICA D:56PF, 1%, 100V CAP., FXD, MICA D:113PF, 2%, 300V CAP., FXD, MICA D:113PF, 2%, 300V CAP., FXD, MICA D:113PF, 2%, 300V	72982 00853 00853 00853 00853	538-011D9-35 D15-1E560F0 D15-3F1130G0 D15-3F1130G0 D15-3F1130G0
Π	C818 C824 C830 C836 C840	283-0603-00 283-0603-00 283-0603-00 283-0603-00 283-0603-00		CAP.,FXD,MICA D:113PF,2%,300V CAP.,FXD,MICA D:113PF,2%,300V CAP.,FXD,MICA D:113PF,2%,300V CAP.,FXD,MICA D:113PF,2%,300V CAP.,FXD,MICA D:113PF,2%,300V	00853 00853 00853 00853 00853	D15-3F1130G0 D15-3F1130G0 D15-3F1130G0 D15-3F1130G0 D15-3F1130G0
П	C842 C844	281-0092-00 281-0092-00		CAP., VAR, CER DI:9-35PF CAP., VAR, CER DI:9-35PF	72982 72982	538-011D9-35 538-011D9-35
_ (

Ckt No.	Tektronix Part No.	Serial/Model No. Eff Dscont	Name & Description	Mfr Code	Mfr Part Number	
C846 C848 C850 C852 C858	283-0637-00 283-0680-00 283-0603-00 283-0603-00 283-0603-00		CAP.,FXD,MICA D:20PF,+/-0.5PF,100V CAP.,FXD,MICA D:330PF,1%,500V CAP.,FXD,MICA D:113PF,2%,300V CAP.,FXD,MICA D:113PF,2%,300V CAP.,FXD,MICA D:113PF,2%,300V	00853		
C864 C870 C875 C876 C880	283-0603-00 283-0603-00 290-0527-00 283-0600-00 283-0639-00		CAP.,FXD,MICA D:113PF,2%,300V CAP.,FXD,MICA D:113PF,2%,300V CAP.,FXD,ELCTLT:15UF,20%,20V CAP.,FXD,MICA D:43PF,5%,500V CAP.,FXD,MICA D:56PF,1%,100V	00853 90201	D15-3F1130G0 D15-3F1130G0 TDC156M020FL DM10E430J0500 D15-1E560F0	
C882 C900 C905 C910 C925	281-0092-00 290-0324-00 290-0527-00 290-0324-00 290-0369-00		CAP., VAR, CER DI:9-35PF CAP., FXD, ELCTLT:750UF, +75-10%, 40V CAP., FXD, ELCTLT:15UF, 20%, 20V CAP., FXD, ELCTLT:750UF, +75-10%, 40V CAP., FXD, ELCTLT:800UF, +75-10%, 15V	72982 56289 90201 56289 56289	39D757G040HJ4 TDC156M020FL 39D757G040HJ4	
C968 C970	281-0091-00 290-0369-00		CAP., VAR, CER DI:2-8PF CAP., FXD, ELCTLT:800UF, +75-10%, 15V	72982 5 62 89		
CR675 CR700 CR710	152-0141-02 152-0199-00 152-0199-00		SEMICOND DEVICE:SILICON,30V,150MA SEMICOND DEVICE:SILICON,BRIDGE,200V,1500MA SEMICOND DEVICE:SILICON,BRIDGE,200V,1500MA	81483	CD8220 66-8039 66-8039	
DS9400 DS9500 DS9600	150-0109-00 150-0035-00 150-0109-00		LAMP, INCAND:18V,26MA LAMP,GLOW:90V,0.3MA LAMP,INCAND:18V,26MA		CM7220 AlD-T CM7220	
F9800	159-0042-00		FUSE, CARTRIDGE: 0.75A, 3AG, FAST-BLO	71400	AGC3-4	
J9010 J9014 J9500 J9550 J9650	131-0148-00 131-0324-00 131-0779-00 131-0779-00 131-1084-00		CONN, RECP, ELEC: 24 CONTACTS CONN, RECP, ELEC: 24 PIN JACK, TIP: GREY PLASTIC INSULATOR JACK, TIP: GREY PLASTIC INSULATOR CONN, RECP, ELEC: 6A, 250V	71785 98291 98291	26-190-24-1004 57-40240(398) SKT-0804 SKT-0804 EAC-301	U
J9943 J9963 J9983	131-1097-00 131-1097-00 131-1097-00		CONN, RECP, ELEC: BNC, FEMALE CONN, RECP, ELEC: BNC, FEMALE CONN, RECP, ELEC: BNC, FEMALE	24931	28JR220-1 28JR220-1 28JR220-1	
K47 5	148-0034-00		RELAY ARMATURE: DPDT, 15V	80009	148-0034-00	
L350 L450 L550 L650 L750	108-0673-00 108-0673-00 108-0673-00 108-0759-00 108-0759-00		COIL,FXD:2.2UH COIL,FXD:2.2UH COIL,FXD:2.2UH COIL,FXD:2UH COIL,FXD:2UH	80009 80009 80009 80009	108-0673-00 108-0673-00 108-0759-00	
L800 L805 L810 L815 L820	108-0072-00 108-0072-00 108-0072-00 108-0072-00 108-0072-00		COIL,FXD:0.75UH COIL,FXD:0.75UH COIL,FXD:0.75UH COIL,FXD:0.75UH COIL,FXD:0.75UH			
L825 L830 L840 L845 L850	108-0072-00 108-0072-00 108-0072-00 108-0072-00 108-0759-00		COIL,FXD:0.75UH COIL,FXD:0.75UH COIL,FXD:0.75UH COIL,FXD:0.75UH COIL,FXD:2UH	80009 80009 80009 80009	108-0072-00 108-0072-00 108-0072-00 108-0072-00 108-0759-00	
L855 L860 L865 L870 L875	108-0072-00 108-0072-00 108-0072-00 108-0072-00 108-0072-00		COIL, FXD: 0.75UH	80009 80009 80009 80009 80009	108-0072-00 108-0072-00 108-0072-00 108-0072-00 108-0072-00	
P9010 P9014	131-0149-00 131-0325-00		CONN, RECP, ELEC: 24 CONTACT CONN, PLUG, ELEC: 24 PIN	02660 71785	26-159-24 57-30240-398	
Q221	151-0134-00		TRANSISTOR: SILICON, PNP	04713	2N2905A	

į,	,	Tektronix	Seria	I/Mod	el No.		Mfr	
	Ckt No.	Part No.	Eff		Dscont	Name & Description	Code	Mfr Part Number
	Q223	151-0301-00				TRANSISTOR: SILICON, PNP	04713	2N2907A
	Q261	151-0134-00				TRANSISTOR: SILICON, PNP	04713	2N2905A
	Q263	151-0301-00				TRANSISTOR: SILICON, PNP	04713	2N2907A
	Q301A,B Q340	151-0232-00 151-0192-00				TRANSISTOR:SILICON, NPN, DUAL TRANSISTOR:SILICON, NPN	12040 04713	NS7348 SS2110
	2	202 0232 00					0.7.25	552114
	Q391A,B					TRANSISTOR: SILICON, NPN, DUAL	12040	
	Q415 Q508	151-0410-00 151-0367-00				TRANSISTOR:SILICON,PNP TRANSISTOR:SILICON,NPN,SEL FROM 3571TP	04713 80009	SPS6765 151-0367-00
	Q512	151-1039-00				TRANSISTOR: SILICON, JFE, P CHANNEL	80009	
	Q5 61	151-0410-00				TRANSISTOR: SILICON, PNP	04713	SPS6765
	Q563	151-0367-00				TRANSISTOR: SILICON, NPN, SEL FROM 3571TP	80009	151-0367-00
	Q576	151-0192-00				TRANSISTOR: SILICON, NPN	04713	SS2110
	Q581	151-0325-00				TRANSISTOR: SILICON, PNP, SEL FROM 2N4258	80009	151-0325-00
	Q642 Q661	151-0301-00 151-0301-00				TRANSISTOR: SILICON, PNP TRANSISTOR: SILICON, PNP	04713 04713	
	2001	131 0301 00				THE RESIDENCE TO THE SECOND SE		
	Q663	151-0134-00				TRANSISTOR: SILICON, PNP	04713	
	Q742 Q864A,B	151-0192-00 151-0232-00				TRANSISTOR:SILICON, NPN TRANSISTOR:SILICON, NPN, DUAL	04713 12040	SS2110 NS7348
	200111,2	101 4101 00						
	R100	315-0101-00				RES., FXD, COMP:100 OHM, 5%, 0.25W		CB1015
	R150 R175	315-0153-00 321-0085-01				RES.,FXD,COMP:15K OHM,5%,0.25W RES.,FXD,FILM:75 OHM,0.25%,0.125W		CB1535 MFF1816G75R00D
	R180	315-0101-00				RES., FXD, COMP: 100 OHM, 5%, 0.25W	01121	CB1015
	R200	321-0200-00				RES., FXD, FILM: 1.18K OHM, 1%, 0.125W	75042	CEAT0-1181F
	R205	321-0193-00				RES., FXD, FILM: 1K OHM, 1%, 0.125W	75042	CEAT0-1001F
	R210	311-1564-00				RES., VAR, NONWIR:500 OHM, 20%, 0.5W	73138	91A-500R0M
	R215 R220	321-0193-00 315-0101-00				RES.,FXD,FILM:1K OHM,1%,0.125W RES.,VAR,NONWIR:500 OHM,20%,0.5W RES.,FXD,FILM:1K OHM,1%,0.125W RES.,FXD,COMP:100 OHM,5%,0.25W		CEAT0-1001F CB1015
	R230	308-0104-00				RES.,FXD,WW:167 OHM,1%,5W	63743	1852
	R250	308-0104-00				RES.,FXD,WW:167 OHM,1%,5W	63743	1852
	R260	315-0101-00				RES.,FXD,COMP:100 OHM,5%,0.25W	01121	CB1015
	R265	321-0193-00				RES.,FXD,FILM:1K OHM,1%,0.125W		CEAT0-1001F
	R270 R275	321-0193-00 321-0085-01				RES.,FXD,FILM:1K OHM,1%,0.125W RES.,FXD,FILM:75 OHM,0.25%,0.125W	75042 91637	CEAT0-1001F MFF1816G75R00D
	D200	271-1564-00				RES., VAR, NONWIR:500 OHM, 20%, 0.5W	73138	91A-500R0M
	R280 R285	311-1564-00 303-0471-00				RES.,FXD,COMP:470 OHM,5%,1W	01121	
	R300	321-0193-00				RES.,FXD,FILM:1K OHM,1%,0.125W		CEATO-1001F
	R305	315-0152-00				RES.,FXD,COMP:1.5K OHM,5%,0.25W RES.,FXD,FILM:1K OHM,1%,0.125W		CB1525 CEAT0-1001F
	R310	321-0193-00				RES.,FXD,FILM:IR OHM,18,0.123W	73042	Chaid-1001r
	R315	315-0151-00				RES., FXD, COMP: 150 OHM, 5%, 0.25W		CB1515
	R320 R325	315-0471-00 315-0302-00				RES.,FXD,COMP:470 OHM,5%,0.25W RES.,FXD,COMP:3K OHM,5%,0.25W		CB4715 CB3025
	R360	315-0302-00				RES., FXD, COMP25W 9.1K OHM, 5%, 0.		CB9125
	R365	315-0151-00				RES.,FXD,COMP:150 OHM,5%,0.25W	01121	CB1515
	R370	315-0752-00				RES., FXD, COMP: 7.5K OHM, 5%, 0.25W	01121	CB7525
	R371	311-0635-00				RES., VAR, NONWIR: 1K OHM, 10%, 0.50W		62-56-1
	R375	315-0104-00				RES., FXD, COMP: 100K OHM, 5%, 0.25W		CB1045 CB4715
	R380 R385	315-0471-00 315-0152-00				RES.,FXD,COMP:470 OHM,5%,0.25W RES.,FXD,COMP:1.5K OHM,5%,0.25W		CB1525
						RES.,FXD,COMP:150 OHM,5%,0.25W	01121	CB1515
	R390 R3 9 5	315-0151-00 315-0302-00				RES.,FXD,COMP:150 OHM,5%,0.25W		CB3025
	R400	321-0193-00				RES.,FXD,FILM:1K OHM,1%,0.125W		CEATO-1001F
	R410	321-0193-00				RES., FXD, FILM: 1K OHM, 1%, 0.125W		CEAT0-1001F CEAT0-1181F
	R415	321-0200-00				RES., FXD, FILM:1.18K OHM, 1%, 0.125W	75042	
	R420	315-0391-00				RES., FXD, COMP: 390 OHM, 5%, 0.25W		CB3915
	R465	321-0296-00				RES.,FXD,FILM:11.8K OHM,1%,0.125W RES.,FXD,FILM:3.16K OHM,1%,0.125W	75042 75042	CEAT0-1182F CEAT0-3161F
	R470 R475	321-0241-00 315-0101-00				RES.,FXD,COMP:100 OHM,18,0.125W	01121	
	R485	315-0472-00				RES., FXD, COMP: 4.7K OHM, 5%, 0.25W	01121	CB4725
	R490	321-0145-00				RES.,FXD,FILM:316 OHM,1%,0.125W	75042	CEAT0-3160F
)							

RES. FED. COMP-12-00 RES. FED. COMP-13-0 OWN, SS, 12 May Comp-13-0 OWN, SS, 12	Ckt No.	Tektronix Part No.	Serial/Model No. Eff Dsconf	Name & Description	Mfr Code	Mfr Part Number	
## ## ## ## ## ## ## ## ## ## ## ## ##	R500 R503 R510	303-0471-00 311-0635-00 315-0151-00		RES.,FXD,COMP:470 OHM,5%,1W RES.,VAR,NONWIR:1K OHM,10%,0.50W RES.,FXD,COMP:150 OHM,5%,0.25W	01121 80740 01121	GB4715 62-56-1 CB1515	
RES., FXD, COMP. 16.2 R. O.M., 54, 0.2 SW 01121 CB6225 CB65 315-0201-00 RES., FXD, COMP. 120 CBM., 54, 0.2 SW 01121 CB1025 CB65 315-0201-00 RES., FXD, COMP. 120 CBM., 54, 0.2 SW 01121 CB2015 CB56 315-0201-00 RES., FXD, COMP. 120 CBM., 54, 0.2 SW 01121 CB2015 CB56 315-0201-00 RES., FXD, COMP. 120 CBM., 54, 0.2 SW 01121 CB1025 CB56 315-0102-00 RES., FXD, COMP. 120 CBM., 54, 0.2 SW 01121 CB1025 CB56 315-0101-00 RES., FXD, COMP. 120 CBM., 54, 0.2 SW 01121 CB1025 CB56 315-0101-00 RES., FXD, COMP. 120 CBM., 54, 0.2 SW 01121 CB1025 CB56 315-0101-00 RES., FXD, FXD, FXD, FXD, FXD, FXD, FXD, FXD	R530 R535 R540	321-0193-00 315-0151-00 315-0151-00		RES.,FXD,FILM:1K OHM,1%,0.125W RES.,FXD,COMP:150 OHM,5%,0.25W RES.,FXD,COMP:150 OHM,5%,0.25W	75042 01121 01121	CEAT0-1001F CB1515 CB1515	
RS57 315-0102-00 RES.,FED,COMP:1R OHM,5%,0.25W 01121	R555 R560 R565	315-0622-00 301-0102-00 315-0201-00		RES.,FXD,COMP:6.2K OHM,5%,0.25W RES.,FXD,COMP:1K OHM,5%,0.50W RES.,FXD,COMP:200 OHM,5%,0.25W	01121 01121 01121	CB6225 EB1025 CB2015	
R600 315-0123-00 RES.,FXD,COMP:12R ORM,5\$,0.25W 01121 CB1235 R615 315-0202-00 RES.,FXD,COMP:2R ORM,5\$,0.25W 01121 CB2025 R635 315-0202-00 RES.,FXD,COMP:2R ORM,5\$,0.25W 01121 CB2025 R630 321-0193-00 RES.,FXD,FILM:1R ORM,1\$,0.125W 75042 CEATO-1001F R640 315-0100-00 RES.,FXD,FILM:1R ORM,1\$,0.125W 01121 CB1005 R655 321-0394-00 RES.,FXD,FILM:1R ORM,5\$,0.25W 01121 CB1005 R657 311-1266-00 RES.,FXD,FILM:2R ORM,1\$,0.125W 75042 CEATO-1243F R657 311-1266-00 RES.,FXD,FILM:2R ORM,1\$,0.125W 73138 C2PT-3490-252R R667 315-0102-00 RES.,FXD,COMP:1SO ORM,5\$,0.25W 01121 CB1025 R675 315-0151-00 RES.,FXD,COMP:1SO ORM,5\$,0.25W 01121 CB1015 R695 321-0164-00 RES.,FXD,COMP:1SO ORM,5\$,0.25W 01121 CB1015 R695 321-0122-00 RES.,FXD,COMP:1SO ORM,5\$,0.25W 01121 CB1015 R695 321-0122-00 RES.,FXD,COMP:1SO ORM,5\$,0.25W 01121 CB1025 R735 315-0302-00 RES.,FXD,COMP:1SO ORM,5\$,0.25W 01121 CB1025 R735 315-0302-00 RES.,FXD,COMP:1SO ORM,5\$,0.25W 01121 CB1025 R735 321-0222-00 RES.,FXD,COMP:1R ORM,5\$,0.25W 01121 CB1025 R735 321-0222-00 RES.,FXD,COMP:1R ORM,5\$,0.25W 01121 CB1025 R735 321-0222-00 RES.,FXD,COMP:1R ORM,5\$,0.25W 01121 CB1025 R736 315-0102-00 RES.,FXD,COMP:1R ORM,5\$,0.25W 01121 CB1025 R736 315-0102-00 RES.,FXD,COMP:1R ORM,5\$,0.25W 01121 CB1025 R736 315-0103-00 RES.,FXD,COMP:1SO ORM,5\$,	R5 7 5 R5 80 R585	315-0102-00 315-0101-00 321-0164-00		RES.,FXD,COMP:1K OHM,5%,0.25W RES.,FXD,COMP:100 OHM,5%,0.25W RES.,FXD,FILM:499 OHM,1%,0.125W	01121 01121 75042	CB1025 CB1015 CEAT0-4990F	
R640 315-0100-00 RES.,FXD,COMP:10 OHM,5%,0.25W 75042 CEAT0-1243F R655 321-0394-00 RES.,FXD,FILM:124K OHM,1%,0.15W 75042 CEAT0-1243F R657 311-1266-00 RES.,FXD,FILM:37.4K OHM,1%,0.15W 75042 CEAT0-3742F R657 311-01266-00 RES.,FXD,FILM:37.4K OHM,1%,0.124W 75042 CEAT0-3742F R656 321-0344-00 RES.,FXD,FILM:37.4K OHM,1%,0.124W 75042 CEAT0-3742F R656 321-0151-00 RES.,FXD,COMP:150 OHM,5%,0.25W 01121 CB1025 R650 321-0183-00 RES.,FXD,COMP:150 OHM,5%,0.25W 01121 CB1515 R680 321-0184-00 RES.,FXD,FILM:3787 OHM,1%,0.125W 75042 CEAT0-7870F R695 315-0151-00 RES.,FXD,FILM:499 OHM,1%,0.125W 75042 CEAT0-4990F R705 315-0151-00 RES.,FXD,COMP:150 OHM,5%,0.25W 01121 CB1515 R710 315-0821-00 RES.,FXD,FILM:2K OHM,5%,0.25W 01121 CB1515 R720 321-0222-00 RES.,FXD,FILM:2K OHM,5%,0.25W 01121 CB3025 R733 315-0102-00 RES.,FXD,COMP:1K OHM,5%,0.25W 01121 CB3025 R733 315-0102-00 RES.,FXD,COMP:1K OHM,5%,0.25W 01121 CB3025 R735 321-0222-00 RES.,FXD,COMP:1K OHM,5%,0.25W 01121 CB1025 R735 321-0222-00 RES.,FXD,FILM:2K OHM,1%,0.125W 75042 CEAT0-2001F R55.FXD,COMP:1K OHM,5%,0.25W 01121 CB1025 R735 321-0222-00 RES.,FXD,COMP:1SO OHM,5%,0.25W 01121 CB1025 R735 315-0103-00 RES.,FXD,COMP:1SO OHM,5%,0.25W 01121 CB1025 R756 311-1556-00 RES.,FXD,COMP:1SO OHM,5%,0.5W 73138 91A-50001M R70 315-0102-00 RES.,FXD,COMP:1SO OHM,5%,0.25W 01121 CB1025 R756 315-0303-00 RES.,FXD,COMP:1OK OHM,5%,0.25W 01121 CB1025 R756 315-0303-00 RES.,FXD,COMP:1OK OHM,5%,0.25W 01121 CB1035 R780 315-0103-00 RES.,FXD,COMP:10K OHM,5%,0.25W 01121 CB1035 R780 315-0103-00 RES.,FXD,COMP:10K OHM,5%,0.25W 01121 CB1035 R790 310-0271-00 RES.,FXD,COMP:10K OHM,5%,0.25W 01121 CB2715 R790 310-0271-00 RES.,FXD,COMP:10K OHM,5%,0.25W 01121 CB2715 R79	R600 R610 R615	315-0123-00 308-0314-00 315-0202-00		RES.,FXD,COMP:12K OHM,5%,0.25W RES.,FXD,WW:680 OHM,5%,3W RES.,FXD,COMP:2K OHM,5%,0.25W	01121 63743 01121	CB1235 25697 CB2025	
R675 315-0151-00 RES.,FXD,COMP:150 OHM,5%,0.25W 01121 CB1515 R680 321-0183-00 RES.,FXD,FILM:787 OHM,1%,0.125W 75042 CEAT0-7870F R695 321-0164-00 RES.,FXD,FILM:499 OHM,1%,0.125W 75042 CEAT0-4990F R705 315-0151-00 RES.,FXD,COMP:150 OHM,5%,0.25W 01121 CB1515 R710 315-0821-00 RES.,FXD,COMP:150 OHM,5%,0.25W 01121 CB1515 R710 315-0821-00 RES.,FXD,COMP:820 OHM,5%,0.25W 01121 CB8215 R720 321-0222-00 RES.,FXD,COMP:18 OHM,5%,0.25W 01121 CB3025 R730 315-0102-00 RES.,FXD,COMP:18 OHM,5%,0.25W 01121 CB3025 R735 321-0222-00 RES.,FXD,COMP:18 OHM,5%,0.25W 01121 CB1025 R735 321-0222-00 RES.,FXD,COMP:18 OHM,5%,0.25W 01121 CB1025 R735 321-0222-00 RES.,FXD,COMP:18 OHM,5%,0.25W 01121 CB1025 R735 321-0222-00 RES.,FXD,COMP:750 OHM,5%,0.25W 01121 CB1025 R756 311-1556-00 RES.,FXD,COMP:750 OHM,5%,0.50W 75042 CEAT0-2001F R756 311-1556-00 RES.,FXD,COMP:18 OHM,20%,0.5W 73138 91A-50001M R770 315-0102-00 RES.,FXD,COMP:30 OHM,5%,0.25W 01121 CB1025 R775 315-0303-00 RES.,FXD,COMP:30 OHM,5%,0.25W 01121 CB3035 R780 315-0103-00 RES.,FXD,COMP:10 OHM,5%,0.25W 01121 CB3035 R780 315-0103-00 RES.,FXD,COMP:10 OHM,5%,0.25W 01121 CB1035 R795 315-0151-00 RES.,FXD,COMP:10 OHM,5%,0.25W 01121 CB1035 R795 321-0081-00 RES.,FXD,COMP:150 OHM,5%,0.25W 01121 CB1035 R795 321-0081-00 RES.,FXD,COMP:150 OHM,5%,0.25W 01121 CB1515 R795 321-0081-00 RES.,FXD,COMP:150 OHM,5%,0.25W 01121 CB1515 R795 321-0081-00 RES.,FXD,COMP:150 OHM,5%,0.50W 73138 91A-10000M R864 311-1563-00 RES.,FXD,COMP:51X0 OHM,5%,0.25W 01121 CB2715 R890 315-0152-00 RES.,FXD,COMP:5.1K0 OHM,5%,0.25W 01121 CB5125 R885 315-0512-00 RES.,FXD,COMP:5.1K0 OHM,5%,0.25W 01121 CB5125 R885 315-0271-00 RES.,FXD,COMP:5.1K0 OHM,5%,0.25W 01121 CB5125 R885 315-0271-00 RES.,FXD,COMP:5.1K0 OHM,5%,0.25W 01121 CB5125	R640 R655 R657	315-0100-00 321-0394-00 311-1266-00		RES.,FXD,FILM:1K OHM,1%,0.125W RES.,FXD,COMP:10 OHM,5%,0.25W RES.,FXD,FILM:124K OHM,1%,0.125W RES.,VAR,COMP:2.5K OHM,10%,0.5W RES.,FXD,FILM:37.4K OHM,1%,0.124W	75042 01121 75042 73138 75042	CB1005 CEAT0-1243F 62PT-3490-252K	
R720 321-0222-00 RES.,FXD,FILM:2K OHM,1\$,0.125W 75042 CEATO-2001F R725 315-0302-00 RES.,FXD,COMP:3K OHM,5\$,0.25W 01121 CB3025 R730 315-0102-00 RES.,FXD,COMP:1K OHM,5\$,0.25W 01121 CB1025 R735 321-0222-00 RES.,FXD,FILM:2K OHM,1\$,0.125W 75042 CEATO-2001F R745 301-0751-00 RES.,FXD,COMP:750 OHM,5\$,0.50W 01121 EB7515 R756 311-1556-00 RES.,VAR,NONWIR:50K OHM,20\$,0.5W 73138 91A-50001M R770 315-0102-00 RES.,FXD,COMP:1K OHM,5\$,0.25W 01121 CB1025 R78780 315-0103-00 RES.,FXD,COMP:1K OHM,5\$,0.25W 01121 CB1025 R780 315-0103-00 RES.,FXD,COMP:10K OHM,5\$,0.25W 01121 CB3035 R780 315-0103-00 RES.,FXD,COMP:10K OHM,5\$,0.25W 01121 CB1035 R782 311-1007-00 RES.,FXD,COMP:10K OHM,5\$,0.25W 01121 CB1035 R782 311-1007-00 RES.,FXD,COMP:150 OHM,5\$,0.25W 01121 CB1035 R790 301-0271-00 RES.,FXD,COMP:270 OHM,5\$,0.25W 01121 CB1515 R795 315-0315-00 RES.,FXD,COMP:150 OHM,5\$,0.25W 01121 CB1515 R795 321-0081-00 RES.,FXD,COMP:150 OHM,5\$,0.25W 01121 CB1515 R856 311-1563-00 RES.,FXD,FXD,COMP:270 OHM,5\$,0.5W 73138 91A-10001M R870 315-0912-00 RES.,FXD,COMP:9.1K OHM,20\$,0.5W 73138 91A-10001M R870 315-0912-00 RES.,FXD,COMP:9.1K OHM,20\$,0.5W 73138 91A-10001M R870 315-0512-00 RES.,FXD,COMP:9.1K OHM,5\$,0.25W 01121 CB5125 R880 315-0512-00 RES.,FXD,COMP:9.1K OHM,5\$,0.25W 01121 CB5125 R890 315-0152-00 RES.,FXD,COMP:15.1K OHM,5\$,0.25W 01121 CB5125 R890 315-0152-00 RES.,FXD,COMP:15.1K OHM,5\$,0.25W 01121 CB5125 R890 315-0152-00 RES.,FXD,COMP:15.1K OHM,5\$,0.25W 01121 CB5125 R890 315-0152-00 RES.,FXD,COMP:15.5K OHM,5\$,0.25W 01121 CB5125 R890 315-0152-00 RES.,FXD,COMP:15.5K OHM,5\$,0.25W 01121 CB5125	R675 R680 R695	315-0151-00 321-0183-00 321-0164-00		RES.,FXD,COMP:150 OHM,5%,0.25W RES.,FXD,FILM:787 OHM,1%,0.125W RES.,FXD,FILM:499 OHM,1%,0.125W	01121 75042 75042	CB1515 CEAT0-7870F CEAT0-4990F	
R756 311-1556-00 RES.,VAR,NONWIR:50K OHM,20%,0.5W 73138 91A-50001M R770 315-0102-00 RES.,FXD,COMP:1K OHM,5%,0.25W 01121 CB1025 R775 315-0303-00 RES.,FXD,COMP:30K OHM,5%,0.25W 01121 CB3035 R780 315-0103-00 RES.,FXD,COMP:10K OHM,5%,0.25W 01121 CB1035 RES.,FXD,COMP:10K OHM,5%,0.25W 01121 CB1035 RES.,FXD,COMP:10K OHM,5%,0.25W 01121 CB1035 RES.,FXD,COMP:150 OHM,5%,0.25W 01121 CB1515 R790 301-0271-00 RES.,FXD,COMP:150 OHM,5%,0.25W 01121 CB1515 R795 321-0081-00 RES.,FXD,FILM:68.1 OHM,1%,0.125W 75042 CEAT0-68R10F R856 311-1563-00 RES.,FXD,FILM:68.1 OHM,1%,0.125W 75042 CEAT0-68R10F RES.,VAR,NONWIR:1K OHM,20%,0.5W 73138 91A-10000M R870 315-0912-00 RES.,FXD,COMP:9.1K OHM,20%,0.5W 73138 91A-10001M R870 315-0912-00 RES.,FXD,COMP:5.1K OHM,5%,0.25W 01121 CB9125 R880 315-0512-00 RES.,FXD,COMP:5.1K OHM,5%,0.25W 01121 CB5125 R885 315-0271-00 RES.,FXD,COMP:270 OHM,5%,0.25W 01121 CB5125 R890 315-0152-00 RES.,FXD,COMP:270 OHM,5%,0.25W 01121 CB5125 R890 315-0152-00 RES.,FXD,COMP:1.5K OHM,5%,0.25W 01121 CB5125 R890 315-0152-00 RES.,FXD,FILM:3.01K OHM,1%,0.125K 75042 CEAT0-3011F	R720 R725 R730	321-0222-00 315-0302-00 315-0102-00		RES.,FXD,FILM:2K OHM,1%,0.125W RES.,FXD,COMP:3K OHM,5%,0.25W RES.,FXD,COMP:1K OHM,5%,0.25W	75042 01121 01121	CEAT0-2001F CB3025 CB1025	
R785 315-0151-00 RES.,FXD,COMP:150 OHM,5%,0.25W 01121 CB1515 R790 301-0271-00 RES.,FXD,COMP:270 OHM,5%,0.50W 01121 EB2715 R795 321-0081-00 RES.,FXD,FILM:68.1 OHM,1%,0.125W 75042 CEAT0-68R10F R856 311-1563-00 RES.,VAR,NONWIR:1K OHM,20%,0.5W 73138 91A-10000M R864 311-1559-00 RES.,VAR,NONWIR:10K OHM,20%,0.5W 73138 91A-10000M R870 315-0912-00 RES.,FXD,COMP:9.1K OHM,5%,0.25W 01121 CB9125 R880 315-0512-00 RES.,FXD,COMP:5.1K OHM,5%,0.25W 01121 CB5125 R885 315-0271-00 RES.,FXD,COMP:270 OHM,5%,0.25W 01121 CB2715 R890 315-0152-00 RES.,FXD,COMP:1.5K OHM,5%,0.25W 01121 CB1525 R930 321-0239-00 RES.,FXD,COMP:1.5K OHM,5%,0.25W 01121 CB1525	R756 R770 R775	311-1556-00 315-0102-00 315-0303-00		RES., VAR, NONWIR:50K OHM, 20%, 0.5W RES., FXD, COMP:1K OHM, 5%, 0.25W RES., FXD, COMP:30K OHM, 5%, 0.25W	73138 01121 01121	91A-50001M CB1025 CB3035	
R870 315-0912-00 RES.,FXD,COMP:9.1K OHM,5%,0.25W 01121 CB9125 R880 315-0512-00 RES.,FXD,COMP:5.1K OHM,5%,0.25W 01121 CB5125 R885 315-0271-00 RES.,FXD,COMP:270 OHM,5%,0.25W 01121 CB2715 R890 315-0152-00 RES.,FXD,COMP:1.5K OHM,5%,0.25W 01121 CB1525 R930 321-0239-00 RES.,FXD,FILM:3.01K OHM,1%,0.125K 75042 CEATO-3011F	R785 R790 R795	315-0151-00 301-0271-00 321-0081-00		RES.,FXD,COMP:150 OHM,5%,0.25W RES.,FXD,COMP:270 OHM,5%,0.50W RES.,FXD,FILM:68.1 OHM,1%,0.125W	01121 01121 75042	CB1515 EB2715 CEAT0-68R10F	
	R870 R880 R885	315-0912-00 315-0512-00 315-0271-00		RES.,FXD,COMP:9.1K OHM,5%,0.25W RES.,FXD,COMP:5.1K OHM,5%,0.25W RES.,FXD,COMP:270 OHM,5%,0.25W	01121 01121 01121	CB9125 CB5125 CB2715	
R940 321-0242-00 RES.,FXD,FILM:3.24K OHM,1%,0.125W 75042 CEATO-3241F R945 321-0335-00 RES.,FXD,FILM:30.1K OHM,1%,0.125W 75042 CEATO-3012F R955 321-0210-00 RES.,FXD,FILM:1.5K OHM,1%,0.125W 75042 CEATO-1501F	R935 R940 R945	321-0310-00 321-0242-00 321-0335-00		RES.,FXD,FILM:16.5K OHM,1%,0.125W RES.,FXD,FILM:3.24K OHM,1%,0.125W RES.,FXD,FILM:30.1K OHM,1%,0.125W	75042 75042 75042	CEAT0-1651F CEAT0-3241F CEAT0-3012F	

Π_{j}						
п	Ckt No.	Tektronix Part No.	Serial/Model No. Eff Dscont	Name & Description	Mfr Code	Mfr Part Number
 	R960 R965 R968 R9070 R9080	315-0153-00 321-0081-00 311-1007-00 321-0203-00 321-0232-00		RES.,FXD,COMP:15K OHM,5%,0.25W RES.,FXD,FILM:68.1 OHM,1%,0.125W RES.,VAR,NONWIR:20 OHM,20%,0.50W RES.,FXD,FILM:1.27K OHM,1%,0.125W RES.,FXD,FILM:2.55K OHM,1%,0.125W	01121 75042 80294 75042 75042	CEAT0-68R10F 3329HG48-200 CEAT0-1271F
Π	R9090 R9120 R9130 R9140 R9150	321-0277-00 321-0277-00 321-0277-00 321-0232-00 321-0202-00 321-0181-00		RES.,FXD,FILM:7.5K OHM,1%,0.125W RES.,FXD,FILM:7.5K OHM,1%,0.125W RES.,FXD,FILM:2.55K OHM,1%,0.125W RES.,FXD,FILM:1.24K OHM,1%,0.125W RES.,FXD,FILM:1.24K OHM,1%,0.125W	75042 75042 75042 75042 75042 75042	CEAT0-7501F CEAT0-7501F CEAT0-2551F CEAT0-1241F
Π	R9220 R9230 R9240 R9250 R9260	321-0373-00 321-0327-00 321-0299-00 321-0277-00 321-0816-00		RES.,FXD,FILM:75K OHM, 1%,0.125W RES.,FXD,FILM:24.9K OHM,1%,0.125W RES.,FXD,FILM:12.7K OHM,1%,0.125W RES.,FXD,FILM:7.5K OHM,1%,0.125W RES.,FXD,FILM:5K OHM,1%,0.125W	75042 75042 75042 75042 91637	CEAT0-2492F CEAT0-1272F CEAT0-7501F
Π	R9270 R9280 R9290 R9700	321-0246-00 321-0234-00 321-0227-00 316-0224-00		RES.,FXD,FILM:3.57K OHM,1%,0.125K RES.,FXD,FILM:2.67K OHM,1%,0.125W RES.,FXD,FILM:2.26K OHM,1%,0.125W RES.,FXD,COMP:220K OHM,10%,0.25W	75042 75042 75042 01121	CEAT0-2671F
Π		260-1576-00 260-1576-00 262-0974-00 260-1582-00 260-0834-00		SWITCH, PUSH:CORRECTED/UNCORRECTED SWITCH, PUSH:CORRECTED/UNCORRECTED SWITCH ASSY:CORRECTED/UNCORRECTED SWITCH, ROTARY:RELATIVE CHROMA LEVEL SWITCH, TOGGLE:POWER-ON	80009 80009 80009 80009 09353	260-1576-00 260-1576-00 262-0974-00 260-1582-00 7201-SN
Π	Т9900	120-0820-00		XFMR, POWER:	80009	120-0820-00
'' П /	U659 U851 U1000 V1100	155-0032-01 156-0067-00 156-0312-00 156-0312-00		INTEGRATED CKT:INPUT PRE-AMPLIFIER INTEGRATED CKT:OPERATIONAL AMPLIFIER INTEGRATED CKT:VOLTAGE REGULATOR INTEGRATED CKT:VOLTAGE REGULATOR	80009 07263 04713 04713	155-0032-01 UA741 MC7815CP MC7815CP
	VR690	152-0212-00		SEMICOND DEVICE: ZENER, 0.5W, 9V, 5%	04713	SZ50646
Π						
Π						



DIAGRAMS, CIRCUIT BOARD ILLUSTRATIONS, MECHANICAL PARTS LIST, AND PACKAGING

Symbols and Reference Designators

Electrical components shown on the diagrams are in the following units unless noted otherwise:

Capacitors = Values one or greater are in picofarads (pF).


Values less than one are in microfarads (μ F).

Resistors = Ohms (Ω)

Symbols used on the diagrams are based on ANSI Y32.2 1970 and IEEE 315 1971

Logic symbology is based on MIL-STD-806B in terms of positive logic. Logic symbols depict the logic function performed and may differ from the manufacturer's data.

The following special symbols are used on the diagrams:



The following prefix letters are used as reference designators to identify components or assemblies on the diagrams.

LR

Q

Α	Assembly, separable or repairable (circuit board, etc.)
AT	Attenuator, fixed or variable
В	Motor
BT	Battery
C	Capacitor, fixed or variable
CR	Diode, signal or rectifier
DL	Delay line
DS	Indicating device (lamp)
F	Fuse
FL	Filter
Н	Heat dissipating device (heat sink, heat radiator, etc.)
HR	Heater

Connector, stationary portion

Inductor, fixed or variable


R	Resistor, fixed or variable
RT	Thermistor
S	Switch
T	Transformer
TP	Test point
U	Assembly, inseparable or non-repairable (integrated circuit, etc.)
V	Electron tube
VR	Voltage regulator (zener diode, etc.)
Y	Crystal


Transistor or silicon-controlled rectifier


Inductor/resistor combination


Connector, movable portion

K














A














MECHANICAL REPLACEABLE PARTS LIST

PARTS ORDERING INFORMATION

Replacement parts are available from or through your local Tektronix, Inc. Field Office or representative.

Changes to Tektronix instruments are sometimes made to accommodate improved components as they become available, and to give you the benefit of the latest circuit improvements developed in our engineering department. It is therefore important, when ordering parts, to include the following information in your order: Part number, instrument type or number, serial number, and modification number if applicable.

If a part you have ordered has been replaced with a new or improved part, your local Tektronix, Inc. Field Office or representative will contact you concerning any change in part number.

Change information, if any, is located at the rear of this manual.

SPECIAL NOTES AND SYMBOLS

X000 Part first added at this serial number 00X Part removed after this serial number

FIGURE AND INDEX NUMBERS

Items in this section are referenced by figure and index numbers to the illustrations.

INDENTATION SYSTEM

This mechanical parts list is indented to indicate item relationships. Following is an example of the indentation system used in the description column.

1 2 3 4

Assembly and/or Component
Attaching parts for Assembly and/or Component
Detail Part of Assembly and/or Component
Attaching parts for Detail Part
Parts of Detail Part
Attaching parts for Parts of Detail Part

Attaching Parts always appear in the same indentation as the item it mounts, while the detail parts are indented to the right. Indented items are part of, and included with, the next higher indentation. The separation symbol --- * --- indicates the end of attaching parts.

Attaching parts must be purchased separately, unless otherwise specified.

ITEM NAME

In the Parts List, an Item Name is separated from the description by a colon (:). Because of space limitations, an Item Name may sometimes appear as incomplete. For further Item Name identification, the U.S. Federal Cataloging Handbook H6-1 can be utilized where possible.

CROSS INDEX MFR. CODE NUMBER TO MANUFACTURER

MFR.C	CODE MANUFACTURER	ADDRESS	CITY,STATE,ZIP
02660	Bunker-Ramo Corp., The, Amphenol		
09214	Connector Div. General Electric Co., Semi-Conductor	2801 S. 25th Ave.	Broadview, IL 60153
03214	Products Dept., Power Semiconductor		
	Products OPN Sec	W. Genesee St.	Auburn, NY 13021
09353	C and K Components, Inc.	103 Morse Street	Watertown, MA 02172
09422	Plastic Stamping Corp.	2216 W. Armitage Ave.	Chicago, IL 60647
12327	Freeway Washer and Stamping Co.	P. O. Box 05206	Cleveland, OH 44105
22526	Berg Electronics, Inc.	Youk Expressway	New Cumberland, PA 17070
24931	Specialty Connector Co., Inc.	3560 Madison Ave.	Indianapolis, IN 46227
71785	TRW Electronic Components, Cinch Div.	1501 Morse Ave.	Elk Grove Village, IL 60007
73743	Fischer Special Mfg. Co.	446 Morgan St.	Cincinnati, OH 45206
73803	Texas Instruments, Inc., Metallurgical	•	,,
	Materials Div.		Attleboro, MA 02703
74445	Holo-Krome Co.	31 Brook St. West	Hartford, CT 06110
75915	Littelfuse, Inc.	800 E. Northwest Hwy	Des Plaines, IL 60016
78189	Illinois Tool Works, Inc.		
70126	Shakeproof Division	St. Charles Road	Elgin, IL 60126
79136	Waldes, Kohinoor, Inc.	47-16 Austel Place	Long Island City, NY 11101
80009 82389	Tektronix, Inc.	P. O. Box 500	Beaverton, OR 97005
83385	Switchcraft, Inc.	5555 N. Elston Ave.	Chicago, IL 60630
94222	Central Screw Co.	2530 Crescent Dr.	Broadview, IL 60153
95987	Southco, Inc.	4444	Lester, PA 19113
98291	Weckesser Co., Inc. Sealectro Corp.	4444 West Irving Park Rd.	Chicago, IL 60641
98978	International Electronic Research Corp.	225 Hoyt	Mamroneck, NY 10544
20270	international Electionic Research Corp.	135 W. Magnolia Ave.	Burbank, CA 91502

ABBREVIATIONS

н	INCH	FLH	FLAT HEAD	PWR	POWER
#	NUMBER SIZE	FLTR	FILTER	RCPT	RECEPTACLE
ACTR	ACTUATOR	FR	FRAME or FRONT	RES	RESISTOR
ADPTR	ADAPTER	FSTNR	FASTENER	RGD	RIGID
ALIGN	ALIGNMENT	FT	FOOT	RLF	RELIEF
AL	ALUMINUM	FXD	FIXED	RTNR	RETAINER
ASSEM	ASSEMBLED	GSKT	GASKET	SCH	SOCKET HEAD
ASSY	ASSEMBLY	HDL	HANDLE	SCOPE	OSCILLOSCOPE
ATTEN	ATTENUATOR	HEX	HEXAGON	SCR	SCREW
AWG	AMERICAN WIRE GAGE	HEX HD	HEXAGONAL HEAD	SE	SINGLE END
BD	BOARD	HEX SOC	HEXAGONAL SOCKET	SECT	SECTION
BRKT	BRACKET	HLCPS	HELICAL COMPRESSION	SEMICOND	SEMICONDUCTOR
BRS	BRASS	HLEXT	HELICAL EXTENSION	SHLD	SHIELD
BRZ	BRONZE	HV	HIGH VOLTAGE	SHLDR	SHOULDERED
BSHG	BUSHING	IC	INTEGRATED CIRCUIT	SKT	SOCKET
CAB	CABINET	ID	INSIDE DIAMETER	SL	SLIDE
CAP	CAPACITOR	INDENT	INDENTIFICATION	SLFLKG	SELF-LOCKING
CER	CERAMIC	IMPLR	IMPELLER	SLVG	SLEEVING
CHAS	CHASSIS	IN	INCH	SPR	SPRING
CKT	CIRCUIT	INÇAND	INCANDESCENT	SQ	SOUARE
COMP	COMPOSITION	INSUL	INSULATOR	SST	STAINLESS STEEL
CONN	CONNECTOR	INTL	INTERNAL	STL	STEEL
cov	COVER	LPHLDR	LAMPHOLDER	SW	SWITCH
CPLG	COUPLING	MACH	MACHINE	T	TUBE
CRT	CATHODE RAY TUBE	MECH	MECHANICAL	TERM	TERMINAL
DEG	DEGREE	MTG	MOUNTING	THD	THREAD
DWR	DRAWER	NIP	NIPPLE	THK	THICK
ELCTRN	ELECTRON	NON WIRE	NOT WIRE WOUND	TNSN	TENSION
ELEC	ELECTRICAL	OBD	ORDER BY DESCRIPTION	TPG	TAPPING
ELECLT	ELECTROLYTIC	OD	OUTSIDE DIAMETER	V	VOLTAGE
ELEM	ELEMENT	PH BRZ	PHOSPHOR BRONZE	VAR	VARIABLE
EPL	ELECTRICAL PARTS LIST	PL	PLAIN or PLATE	W/	WITH
EQPT	EQUIPMENT	PLSTC	PLASTIC	WSHR	WASHER
EXT	EXTERNAL	PN	PART NUMBER	XFMR	TRANSFORMER
FLEX	FLEXIBLE	PNH	PAN HEAD	XSTR	TRANSISTOR
	· · · · · · · · · · · · · · · · · · ·				

FIGURE 1 EXPLODED

	Fig. & Index	Tektronix	Serial/Mod	el No.				Mfr	
	No.	Part No.		Dscont	Qty	1 2 3 4 5	Name & Description	Code	Mfr Part Number
•	1-1	390-0276-00							
	1-1				 T	CABINET, TOP:	ICI LIDEC .	80009	390-0276-00
	-2	355-0134-00			11	STILL TIPNIOUS	CLUDES: F:FLAT HEAD STEEL ::SPLIT RING PAIR)	04222	02 14 140 16
	-3	214-0389-00			11	FSTNR BETAINER	OSDITT DING	94222 94222	
	-4	351-0104-00			ī	SLIDE SECT:DWR.	DATD	94222	82-32-101-17
	•	331 0101 00			-	Shipe Sections.	TTACHING PARTS)	80009	351-0104-00
	-5	212-0004-00			4	SCREW, MACHINE: 8-	32 X 0.312 INCH, PNH STL	83385	OBD '
							*		
	-6	354-0025-00				RING, RETAINING:		79136	5555-18
	-7	210-0894-00			2		0.190 ID X 0.438 INCH OD	09422	OBD
	-8	213-0216-00			2		X 0.750 INCH LONG, SST	80009	213-0216-00
	-9	367-0160-00			. 2	HANDLE: CARRYING		80009	367-0160-00
	-10	211-0014-00			2	(A	TTACHING PARTS FOR EACH)		
	-10	211-0014-00			2		40 X 0.50 INCH, PNH STL	83385	OBD
	-11	407-1073-00			2		^	00000	407 3070 00
	-11	407-1073-00			2		MMAGUTNG DADMG BOD DAGUL	80009	407-1073-00
	-12	212-0004-00			2	CCDEW MACUINE.O.	TTACHING PARTS FOR EACH) 32 X 0.312 INCH, PNH STL	02205	
	12	212 0004 00			2	SCREW, MACHINE: 6-	*	83385	OBD
	-13	260-0834-00			7	SWITCH TOCCIE.DO	WER, W/HARDWARE ECTED RRECTED N	00353	7201 CV
	-14	131-0779-00			2	TACK TID CDAV	WER, W/ NARDWARE	09353	7201-SN
	-15	366-1161-59			2	DUCK, IIF GRAI	EGMED	98291	016-8010
	-16	366-1161-60			2	DIER DIMMONATING	DDBC@DD	80009	366-1161-59
	-17	426-0568-00			1	FDAME DIEU DIEUM	M	80009	366-1161-60
	-18	426-0360-01			7	FR, KNOB WINDOW:S	N TNCT E	80009	426-0568-00
		.20 0300 02			_	1K, KNOD WINDOW:5	TMACHING DARMS)	80009	426-0360-01
	-19	211-0541-00			2		N INGLE TTACHING PARTS) 32 X 0.25",100 DEG,FLH STL	83385	OBD
	-20	366-0164-05			1	WIOD DIAGE O O M	*		
	-20	213-0004-00			+	KNOB:BLACK,U-9 W	TTH SETSCREW	80009	366-0164-05
	-21	366-0167-04			, <u>,</u>	SETSCREW:6-32	X U.188 INCH, HEX SOC, STL	74445	OBD
	-21	213-0004-00			÷	KNOB:BLACK, U. 6-1	.5 WITH SETSCREW	80009	366-0167-04
	-22				i	SWITCH, ROTARY:CO	ITH SETSCREW X 0.188 INCH,HEX SOC,STL .5 WITH SETSCREW X 0.188 INCH,HEX SOC,STL NCENTRIC (SEE S900A/B EPL) TTACHING PARTS)	74445	OBD
						(A	TTACHING PARTS)		
	-23	210-0413-00			1	NUT, PLAIN, HEX: 0.	375-32 X 0.50 INCH.STL	73743	3145-402
	-24	210-0012-00				•	,0.375 ID X 0.50"OD,STL		
	-25	406-0757-00			1	BRKT, ELEC SW:		80009	406-0757-00
	26	222 1704 00			-		*		
	-26	333-1794-00			1	PANEL, FRONT:	TTACHING PARTS) 6-32 X 0.312 INCH,STL	80009	333-1794-00
	-27	210 0457 00			,	(A	TTACHING PARTS)		
		210-0457-00			ţ	NUT, PLAIN, EXT W:	6-32 X 0.312 INCH, STL	83385	OBD
	-28	200-0609-00			Ţ	BASE, LAMPHOLDER:		80009	200-0609-00
	-29 -30	378-0541-00			Ţ	LENS, LIGHT: FROST	ED	80009	378-0541-00
		352-0084-00			<u> </u>	HOLDER, NEON:		80009	352-0084-00
	-31	200-0935-00			2	BASE, LAMPHOLDER:		80009	
	-32 -33	378-0602-00			Ţ	LENS, LIGHT: GREEN		80009	378-0602-00
	-33 -34	378-0602-02			Ţ	LENS, LIGHT: RED		80009	378-0602-02
	-3 5	352-0157-01			2	LAMPHOLDER: BLACK	-APERATURE (SEE Al EPL)	80009	352-0157-01
	33				_		TTACHING PARTS)		
	-36	211-0116-00			4	SCR, ASSM WSHR: 4-	40 X 0.312 INCH, PNH BRS	83385	OBD
							*		
	2.7	121 0500 00			-	CKT BOARD ASSY			
	-37	131-0589-00			32	CONTACT, ELEC: 0		22526	
	20	131-0608-00			4		.365 INCH LONG	22526	
	-38	131-0998-00			1		M,8.132 INCH LONG, CUT TO FIT		131-0998-00
	-39	136-0235-00			3	SOCKET, XSTR:6			133-96-12-062
	-40	136-0252-04			47	SOCKET, CONN PI		22526	
	-41	136-0260-02			1	SOCKET, IC:16 P			C931602
	-42	260-1576-00			2	SWITCH, PUSH: DO		80009	
	-43	361-0384-00			8		RED, 0.133 INCH LONG	80009	361-0384-00
	-44	385-0033-00			1	INS,STANDOFF:0		80009	385-0033-00
	-45	211-0504-00			1		TTACHING PARTS) 6-32 X 0.25 INCH,PNH STL	02205	OPD
	-40	**************************************			1		-32 X U.25 INCH, PNH STL	83385	OBD
	-46	214-0269-00			2	HEAT SINK, ELEC		98978	TDX032-075
	-47	131-0707-00			2		:0.50 INCH LONG(22-26 AWG)	22526	
	-48	352-0169-00			ī		N:2 WIRE (BLACK)		352-0169-00
	-	-			_	,,			

FIGURE 1 EXPLODED (cont)


Fig. & Index No.	Tektronix Part No.	Serial/Model No. Eff Dscont	Qty	1 2 3 4 5 Name & Description	Mfr Code	Mfr Part Number
1-49			1	TRANSFORMER: (SEE T9900 EPL)		
F0	211 0512 00			(ATTACHING PARTS)		
-50 -51	211-0513-00 210-0802-00		4	SCREW, MACHINE: 6-32 X 0.625 INCH, PNH STL WASHER, FLAT: 0.150 ID X 0.312 INCH OD, STL	83385 12327	
-52	210-0006-00			WASHER, LOCK: INTL, 0.461 ID X 0.283"OD, STL	78189	
-53	129-0391-00		4	POST, ELEC-MECH: HEX 0.375 X 0.375 INCH LONG		129-0391-00
-54	343-0002-00		2	CLAMP, LOOP: CABLE	05007	3-16-6P
-34	343-0002-00			(ATTACHING PARTS FOR EACH)	33367	3-16-6B
-55	211-0025-00			SCREW, MACHINE: 4-40 X 0.375"100 DEG, FLH STL	83385	OBD
-56	210-0586-00		1	NUT, PLAIN, EXT W:4-40 X 0.25 INCH, STL WASHER, FLAT: 0.150 ID X 0.375 INCH OD, STL	83385	
-57	210-0803-00		1	WASHER, FLAT: 0.150 ID X 0.375 INCH OD, STL	12327	OBD
-58			1	INTEGRATED CKT: (SEE U1000 EPL)		
-59	210-0586-00		1	(ATTACHING PARTS) NUT,PLAIN,EXT W:4-40 X 0.25 INCH,STL	83385	OBD
-60			1	INTEGRATED CKT: (SEE U1100 EPL)		
				(ATTACHING PARTS)		
-61	210-0586-00		1	NUT, PLAIN, EXT W:4-40 X 0.25 INCH, STL WASHER, SHLDR:0.116 ID X 0.138 OD, NYLON	83385	
-62 -63	210-1171-00			WASHER, SHLDR: 0.116 ID X 0.138" OD, NYLON		A7148516P2
-03	342-0163-00		1	INSULATOR:MICA, 0.675 X 0.625 INCH	80009	342-0163-00
-64	131-1084-00		1	CONN, RECP, ELEC: AC INPUT (ATTACHING PARTS)	82389	EAC-301
-65	211-0012-00		2	SCREW, MACHINE: 4-40 X 0.375 INCH, PNH STL NUT, PLAIN, EXT W: 4-40 X 0.25 INCH, STL	83385	OBD
-66	210-0586-00	•			83385	
-67	352-0362-00		1	FUSEHOLDER: WITH MOUNTING HARDWARE	75915	
-68	131-0149-00		1	CONN,RCPT,ELEC:MALE 24 PIN (ATTACHING PARTS) SCREW,MACHINE:4-40 X 0.375 INCH,PNH STL TERMINAL,LUG:0.094 INCH DIAMETER,SE NUT,PLAIN,EXT W:4-40 X 0.25 INCH,STL	02660	
-69	211-0012-00		2	SCREW, MACHINE: 4-40 X 0.375 INCH, PNH STL	83385	
-70 71	210-0201-00		2	TERMINAL, LUG: 0.094 INCH DIAMETER, SE	78189	
-71	210-0586-00		2	NOT, PLAIN, EXT W:4-40 X 0.25 INCH, STL	83385	ORD
-72	210-0202-00		1	TERMINAL, LUG:SE #6 (ATTACHING PARTS)	78189	2104-06-00-2520N
-73	210-0457-00		1	NUT, PLAIN, EXT W:6-32 X 0.312 INCH, STL	83385	OBD
-74	441-1186-00		1	CHAS, ELEC EQUIP: MAIN CHASSIS INCLUDES:	80009	441-1186-00
-75	214-0388-00		11	FASTENER RCPT:LEAF SPRING	94222	82-35-295-15
-76	210-0657-01		2	(ATTACHING PARTS FOR EACH) EYELET: 0.089 OD, BARREL, 0.218 INCH LONG	80009	210-0657-01
				*		
-77 -78	129-0105-00		2 1	POST, ELEC-MECH: 0.218 OD X 0.219 INCH LONG CONN, PLUG, ELEC: MALE, 24 PIN	80009	129-0105-00
-78 -79	131-0325-00 131-0324-00		i	CONN, PLUG, ELEC: MALE, 24 PIN CONN, RCPT, ELEC: FEMALE, 24 PIN	71785	57-40240398
, ,	101 0011 00			(ATTACHING PARTS)		3, 10210330
-80	211-0062-00		2	SCREW, MACHINE: 2-56 X 0.312 INCH, PNH STL WASHER, LOCK: 0.092 ID X 0.180 INCH OD, STL NUT, PLAIN, HEX: 2-56 X 0.188 INCH, BRS	83385	
-81	210-0001-00		2	WASHER, LOCK: 0.092 ID X 0.180 INCH OD, STL	78189	1202-00-00-0541C
-82	210-0405-00		2	NUT, PLAIN, HEX: 2-56 X 0.188 INCH, BRS	13143	2X12157-402
-83	131-0148-00		1	CONN, RCPT, ELEC: FEMALE, 24 PIN (ATTACHING PARTS)	02660	26-190-24-1004
-84	211-0014-00		2	SCREW, MACHINE: 4-40 X 0.50 INCH, PNH STL	83385	OBD
-85	129-0371-00		2	POST, ELEC-MECH: 0.25 HEX X 0.83 INCH LONG	80009	129-0371-00
-86	131-1097-00		6	CONN, RCPT, ELEC: BNC, WITH HARDWARE	24931	28JR220-1
-87				CKT BOARD ASSY: RELAY/DELAY (SEE A2 EPL)		
				CKT BOARD ASSY INCLUDES:	22526	47350
-88 -89	131-0589-00 136-0252-04		16 ' 17	CONTACT, ELEC: 0.46 INCH LONG SOCKET, CONN PIN: SINGLE	22526	75060-001
-90	441-1059-00		í	CHAS, ELEC EQUIP: INTERFACE		441-1059-00
-91	179-2126-00		1	WIRING HARNESS: MAIN		179-2126-00
-92	131-0792-00		- 3	WIRING HARNESS INCLUDES: CONNECTOR, TERM: 0.58 INCH LONG(18-20 AWG)	22526	46221
-32	131-0792-00 131-0621-00		17	CONNECTOR, TERM: 0.58 INCH LONG(18-20 AWG) CONNECTOR, TERM: 0.58 INCH LONG(22-26 AWG)	22526	
	131-0622-00		2	CONNECTOR, TERM: 0.58 INCH LONG(28-32 AWG)	22526	
93	352-0199-00		2	HOLDER, TERM CON: 3 WIRE (BLACK)		352-0199-00
-94	352-0200-00		1	HOLDER, TERM CON: 4 WIRE (BLACK)		352-0200-00
-95 -96	352-0205-00 352-0206-00		1 1	HOLDER, TERM CON: 9 WIRE (BLACK) HOLDER, TERM CON: 10 WIRE (BLACK)		352-0205-00 352-0206-00
,,	332 0200 00		-	HOLDEN/IDIA COM-10 HIND (DIRON)	23003	

Mechanical Parts List—1478

FIGURE 1 EXPLODED (cont)

	Fig. & Index No.	Tektronix Part No.	Serial/Model No. Eff Dscont	Qty	у	1 2	3	4 !	5	ŀ	Name &	Description		Mfr Code	Mfr	Part Numbe	·
•	1-	179-2127-00	100	1		WIRIN	iG	на	ARNESS	:RELA	/DELAY	7		80009	179-	-2127-00	
	_			_		WIR	I	NG	HARNI	ESS INC	LUDES:	:					
		131-0792-00		3	}	CON	N.	ECT	ror, Tr	ERM:0.5	8 INCH	H LONG (18-20	AWG)	22526	4622	21	
		131-0621-00		3	1	CON	N.	ECT	IOR TI	ERM:0.5	8 INCH	I LONG (22-26	AWG)	22526	4623	31	
		131-0622-00		3	1	CON	N	ECT	FOR TE	ERM:0.5	8 INCH	I LONG (28-32	AWG)	22526	4624	11	
		352-0200-00		ì						CON: 4				80009	352-	-0200-00	
	-97	352-0202-00		1		HOL	D	ER.	TERM	CON: 6	WIRE (E	BLACK)		80009	352-	-0202-00	

+






Fig. & Index No.	Tektronix Part No.	Serial/Model No. Eff Dscont	Qty	1 2 3 4 5	Name & Description	Mfr Code	Mfr Part Number
2-1	161-0066-00		1	CABLE ASSY, PWR:8	FOOT LONG	80009	161-0066-00
-2	351-0331-00		1	SLIDE GUIDE: (PAI)	R)	80009	351-0331-00
	070-1640-00		1	MANUAL, TECH: (NOT	SHOWN)	80009	070-1640-00





Fig. & Index No.	Tektronix Part No.	Serial/Mod Eff	el No. Dscont	Qty	1 2 3 4 5	Name & Description	Mfr Code	Mfr Part Number
3-	065-0190-00			1	CARTON ASSEMBLY		80009	065-0190-00
				-	CARTON ASSEMBI	LY INCLUDES:		
-1	004-1220-00			4	PAD, CORNER:		80009	004-1220-00
-2	004-1157-00			1	PAD SET:4 PIEC	CES	80009	004-1157-00
-3	004-0849-00			1	CARTON: 24 X 2	3 X 8.250 INCHES	80009	004-0849-00

MANUAL CHANGE INFORMATION

At Tektronix, we continually strive to keep up with latest electronic developments by adding circuit and component improvements to our instruments as soon as they are developed and tested.

Sometimes, due to printing and shipping requirements, we can't get these changes immediately into printed manuals. Hence, your manual may contain new change information on following pages.

A single change may affect several sections. Sections of the manual are often printed at different times, so some of the information on the change pages may already be in your manual. Since the change information sheets are carried in the manual until ALL changes are permanently entered, some duplication may occur. If no such change pages appear in this section, your manual is correct as printed.



TEXT CORRECTIONS

Page 10, right column

CHANGE step 10b to read as follows:

b. Rotate the variable resistor back and forth and adjust C458, R657, and C787 to pass the vector tip through 0 on the horizontal axis. Adjustment of R567 may be necessary to pass the vector tip through zero.

Pages 10 and 11 CHANGE step 11 to read as follows:

- 11. Adjust 2T and T Pulse Tracking
- a. Remove the variable resistor and replace P741. Make the operating change required to change the Test Signal Generator to 2T pulse, consult the Test Signal Generator instruction manual.
- b. Set the front panel CHROMA GAIN to 1.59. Depress PROGRAM CHANNEL CORRECTED and observe the Waveform Monitor.
- c. Adjust the 2T Pulse Tracking, C700, for equal amounts of 2T pulse negative preshoot and baseline overshoot.
- d. Return the Test Signal Generator to T pulse and adjust P. Chroma Gain, R503, for equal negative preshoot and baseline overshoot of the T pulse.

Interacting Steps
Repeat the preceding six steps until no further adjustment is necessary.

ELECTRICAL PARTS LIST AND SCHEMATIC CORRECTION

CHANGE TO:

C458	281-0092-00	CAP., Var, CER D1:9-35 PF
C794	283-0637-00	CAP., FXD, MICA D:20 PF, +/-0.5 PF, 100 V
C968	281-0092-00	CAP., Var, CER D1:9-35 PF
F9800	159-0030-00	FUSE, CARTRIDGE: 0.3A, 3AG, FAST-BLO

CHANGE TO:		
L800	108-0767-00	COIL, FXD, 740 nH
L805	108-0767-00	COIL, FXD, 740 nH
L810	108-0767-00	COIL, FXD, 740 nH
L815	108-0767-00	COIL, FXD, 740 nH
L820	108-0767-00	COIL, FXD, 740 nH
L825	108-0767-00	COIL, FXD, 740 nH
L830	108-0767-00	COIL, FXD, 740 nH
L835	108-0767-00	COIL, FXD, 740 nH
L840	108-0767-00	COIL, FXD, 740 nH
L845	108-0767-00	COIL, FXD, 740 nH
L850	108-0767-00	COIL, FXD, 740 nH
L855	108-0767-00	COIL, FXD, 740 nH
L860	108-0767-00	COIL, FXD, 740 nH
L865	108-0767-00	COIL, FXD, 740 nH
L870	108-0767-00	COIL, FXD, 740 nH
L875	108-0767-00	COIL, FXD, 740 nH
R100	131-0566-00	LINK, TERMINAL CONN. DUMMY RES (OΩ)
R180	131-0566-00	LINK, TERMINAL CONN. DUMMY RES (OΩ)
R595	315-0241-00	RES, FXD, COMP, 240 Ω, 5%, 0.25 W
ADD:		
C700	281-0064-00	CAP., VAR, CER DO.25-1.5 PF, 600 V
R145	315-0301-00	RES., 300 Ω (nominal value) selected
R290	315-0301-00	RES., 300 Ω (nominal value) selected
R582	315-0101-00	RES., FXD, COMP: 100 Ω, 5%, 0.25 W

